


**TIPS:** Each device key is associated with a type of device—the TV is preset to search for TVs, SAT•CBL•DTC for satellite receivers, cable boxes or digital TV converters (DTC), and VCR•DVD for VCRs or DVD players.

The ON•OFF key serves as an indicator light during programming, giving you feedback at each stage of the process. The Manual Code Search method may take a long time because the remote searches through all of the codes in its memory one-by-one. If your brand is listed in the Brand Codes or the Code Lists, first try the Brand Code Search or the Direct Code Entry method.

To exit without saving a new code at any point in the Manual Code Search, press the GO BACK key.


- Manually turn on the device you want to control.




- If you're programming the TV or SAT•CBL•DTC key, go to step 3.

If you're programming the VCR•DVD key, you need to tell the remote which kind of device you want this key to control, VCR or DVD.

Press and hold the VCR•DVD key. While you're holding down the VCR•DVD key, use your other hand to press the number key for the type of device you want to control with this key: 2 for VCR, 3 for DVD.



- Press and hold the device key you want to program. While you're holding down the device key, use your other hand to press and hold the remote's ON•OFF key at the same time.



- Wait until the ON•OFF key comes on and stays on. Then release both keys.

- Point the remote directly at the front panel of the device you want to control. Press ON•OFF on the remote and wait 2 seconds. The remote is testing a single code for your device.



#### Did your device turn off?

**YES:** Press the STOP key to store the code. You're done! You've programmed this device key.

**NO:** Press ON•OFF again. The remote tests the next code for your device.

Keep pressing ON•OFF every 2 seconds until your device turns back on. When it does, press STOP.

**TIP:** Because there are so many codes, you may have to press the ON•OFF key many times—possibly hundreds of times.

#### NOTES

Throughout the programming of each key, keep the remote pointed at the IR sensor of the device you are programming the remote to control.

Test the remote with the device to make sure the device key is programmed with the correct code for maximum functionality. If some features don't work, try a different code. See the "Testing the Code for Maximum Functionality" section below for more information.

During the Manual Code Search, the remote ignores keypresses that aren't part of the search.

The search times out after two minutes (the ON•OFF key blinks four times and turns off, and the last programmed code under that device key is retained).

The ON•OFF key blinks four times and turns off when the remote has gone through all the codes. The remote exits the Manual Code Search. If your device hasn't turned off yet, try a different search method.

#### Testing the Code for Maximum Functionality

1. Try a variety of the device's functions with the remote. If some features of your devices don't work, go to the next step to try a different code.

2. Repeat the Manual Code Search from the beginning. When the device turns off for the first time, don't press the STOP key, which would store the same code. Instead, with the unit now off, continue to press the ON•OFF key repeatedly until the unit turns back on.

3. Once the unit turns back on, you have found another code that operates the device. Press the STOP key.

4. Test the key's functionality again by trying a variety of functions. If the code controls the majority of the device's functions, programming is complete. If the code stored does not give maximum functionality, try another code.

#### Tour of the Remote

In most cases, the keys on this remote perform the same functions as the keys on your original remotes once you've programmed this remote to operate your components. Many keys on this remote have other functions as well.

Illuminated ON•OFF key serves as an indicator light to provide feedback.


Device keys (TV, SAT•CBL•DTC, VCR•DVD) put the remote in the right mode to control your device.

Backlight key ( ) turns backlighting on/off.

GUIDE and MENU put the remote in menu/guide mode, which makes the CH/VOL keys serve as arrow keys; they also access the same features as the keys on your original remotes.

Keep pressing ON•OFF every 2 seconds until your device turns back on. When it does, press STOP.

Actual model may vary from illustration



CH and VOL keys have dual functions: they can act as navigation keys in menu systems as well as channel and volume controllers outside the menus. The CH keys also provide skip forward and skip back control for DVD players and DVRs that support this functionality.

GO BACK exits remote programming; it also performs the same functions as on your original remotes

The INPUT and — (dash) key has three functions: (1) it toggles through all the video sources connected to your TV; (2) when the remote is in VCR mode, this button toggles between VCR and the TV input; (3) when you're entering digital channel numbers directly, this button lets you separate the main channel number from the sub-channel number (such as 59.1)

#### IMPORTANT

Because this remote controls more than one device, you must first "tell" the remote which device you wish to operate. That means, if you wish to operate your TV, you must first press the TV key to put the remote in the TV Mode. The remote stays in that device mode until you press a different device key. For example, if your remote is in TV Mode and you want to operate the DVD player, you must press the VCR•DVD key to change device modes.

#### Backlighting

Backlight illumination helps you see the remote control keys better in the dark. You can turn backlight illumination on or off by pressing the backlight key ( ). Backlighting stays on as long as keys are being pressed and turns off six seconds after the last keypress. Once the backlight time has timed out, any keypress will reactivate it. If the backlight illumination is on, and you press the backlight key, the backlight turns off.

#### Accessing Device Menus and Guides

Many devices use on-screen menus and guides to help you navigate through all their features and programming. While this remote may not access every menu or guide system of every device model, it does offer some menu and guide functionality.

To use a device's on-screen menu or guide system, you first have to put the remote in Menu or Guide Mode.

1. Make sure your devices are turned on and your TV is set to the correct device input (use the INPUT key to toggle through inputs when in TV Mode.)

2. Press the device key whose menu you want to access.

3. To access menus, press the MENU key. To access guides, press the GUIDE key. The ON•OFF key starts blinking, indicating you are in Menu or Guide Mode.

4. Use the VOL+/- and CH+/- keys to navigate through the on-screen menu system or guide. To select the highlighted item, press the OK key.

**TIP:** If the remote doesn't respond, check to see that the ON•OFF key is still blinking. The ON•OFF key times out after 20 seconds. If this happens, just press the MENU key again, and then retry your selection.

#### Exiting Menu/Guide Mode

The remote automatically times out of Menu or Guide Mode after 20 seconds of inactivity (no keys being pressed). At that time, the remote clears the displayed menu from the TV.

If you want to exit the Menu Mode yourself, press the corresponding device key on the remote (TV, SAT•CBL•DTC, VCR•DVD). The ON•OFF key turns off.

## Advanced Functions

#### Code Retrieval


Once you've programmed the remote to control your devices, you may want to record the codes for future reference. If you used the Direct Code Entry method, this is easy. Just find the codes you entered and make a note of them in the boxes below. If you used one of the Code Search methods to program your remote or if you used the Direct Entry method but don't remember the code, you will need to retrieve each device's five-digit code. Retrieving the actual code and writing it down will save you time if you ever need to program the remote again (e.g., if programming is lost when you change the batteries). If the codes are recorded, you can use the Direct Entry method to reprogram your remote to control your devices, which is quick and easy.

- Press and hold the device key (TV, SAT•CBL•DTC, VCR•DVD) whose code you wish to retrieve. The ON•OFF key turns on. Keep pressing the device key.
- While holding the device key down, press and hold the INFO key. The ON•OFF key turns off. After holding down both keys for three seconds, the ON•OFF key turns back on.
- Release both keys. The ON•OFF key remains on.
- Starting with the number 1 key, press and release each number key on the keypad in the following order: 1-9, then 0. The number that causes the ON•OFF key to blink is the first number of the code. As you find each number of the code, write it down for future reference.

- Note:** All TV codes begin with the number 1; all VCR and DVR codes begin with the number 2; all DVDs, the number 3; and all satellite receivers, cable boxes and DTV converters, the number 5.
- Repeat step 4 until you have retrieved all five numbers in the code. After the fifth number is retrieved, the ON•OFF key blinks briefly, then turns off.

**TIP:** To exit the Code Retrieval Mode at any time, press the GO BACK key.

**Note:** If you press an invalid key during the Code Retrieval process, the remote will not respond. If you do not press a valid Code Retrieval key (TV, SAT•CBL•DTC, VCR•DVD, INFO, GO BACK), Code Retrieval times out after 15 seconds. The ON•OFF key blinks four times, and then turns off.



## Troubleshooting

#### Problem: The remote does not operate your device.

- Make sure the remote is in the correct mode by pressing the corresponding device key (TV, SAT•CBL•DTC, VCR•DVD). This tells the remote which device to operate.
- Remove any obstacles between the remote and the device. Make sure you're aiming the remote at the device's IR sensor.
- Make sure the batteries are fresh and are properly installed. Replace the batteries with two new AA batteries, if necessary (see the Battery Installation section).

#### Problem: The remote can't be programmed to operate your device.

- If you are testing the remote while programming it, you may be too far away from the device or at a wrong angle. There must be an unobstructed path between the remote and the IR sensor on the device. Move closer and make sure you point the remote at the device you're trying to control.
- If you're using the Direct Entry programming method to enter the codes for your brand and the unit is still not functioning properly, try the auto, brand, or manual search method.
- To control combo units, like TV/VCRs or TV/DVDs, you must program the individual corresponding device keys to control each part of the combo unit. Once programmed successfully, the TV key controls the TV functions, and the VCR•DVD key controls the VCR or DVD functions.
- Make sure the batteries are fresh and are properly installed.

#### Problem: The remote doesn't perform commands properly.

- Make sure the remote is in the correct mode by pressing the corresponding device key (TV, SAT•CBL•DTC, VCR•DVD). This tells the remote which device to operate.
- Make sure device is ready (for example, the DVD player has a disc loaded).
- You may have pressed an invalid key for the mode the remote is in.
- If you're trying to enter a channel number directly, try pressing the ENTER key after entering the channel number as this is a requirement of certain models and brands.
- There is a possibility that a programmed code may only be able to control some of your device features (for example, only turns a device on and off). To confirm that the device key is programmed with the correct code for maximum functionality, test the device. Attempt to control a variety of the device's functions with the remote. If some of the features of your devices don't work, try programming the remote with a different code in the list using the Direct Code Entry Method, until you find the code that allows the remote to control the majority of your device's functions. Different codes can provide different levels of functionality.

#### Problem: The ON-OFF key does not light when you press a key.

- You may have pressed an invalid key for the mode the remote is in.
- Make sure the remote is in the correct mode by pressing the corresponding device key (TV, SAT•CBL•DTC, VCR•DVD). This tells the remote which device to operate.
- Make sure the batteries are fresh and are properly installed. Replace the batteries with two new AA batteries, if necessary (see the Battery Installation section).

#### Problem: The remote will not change channels on device.

- Make sure the remote is in the correct mode by pressing the corresponding device key (TV, SAT•CBL•DTC, VCR•DVD). This tells the remote which device to operate.
- Press the ENTER key after you enter a channel number.
- Remove any obstacles between the remote and the device. Make sure to aim the remote at the IR sensor on the device.

#### Problem: The device's menu does not appear on the TV screen.

- Make sure you have connected the device to your TV properly and selected the correct input. (See your devices' Owner's Manuals for proper connection procedures.)
  - Make sure the remote is in the correct mode by pressing the corresponding device key (TV, SAT•CBL•DTC, VCR•DVD). This tells the remote which device to operate.
  - Menu access isn't supported for all brands. You may need to use your original remote control to access menu functions for some devices.
- For more information, please visit [www.rcaaccessories.com](http://www.rcaaccessories.com)  
Consumer Help Line: 1-800-420-7968

#### Care and Maintenance

- Keep the remote dry. If it gets wet, wipe it dry immediately.
- Use and store the remote only in normal temperature environments.
- Handle the remote gently and carefully. Don't drop it.
- Keep the remote away from dust and dirt.
- Wipe the remote with a damp cloth occasionally to keep it looking new.
- Modifying or tampering with the remote's internal devices can cause malfunction and invalidate its warranty.

## Limited Lifetime Warranty

Audiovox Electronics Corporation (the "Company") warrants to you the original retail purchaser of this product that should it, under normal use and conditions, be proven defective in material or workmanship during its lifetime while you own it, such defect(s) will be repaired or replaced (at the Company's option) without charge for parts and repair labor. To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to the Company at the address shown below.

This Warranty does not cover product purchased, serviced or used outside the United States or Canada. This Warranty is not transferable and does not extend to costs incurred for installation, removal or reinstallation of the product. This Warranty does not apply if in the Company's opinion, the product has been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or the simultaneous use of different battery types (e.g. alkaline, standard or rechargeable).

THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED TO DURATION OF THIS WARRANTY. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some states/provinces do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights, which vary from state/province to state/province.

**U.S.A.:** Audiovox Electronics Corporation, 150 Marcus Blvd., Hauppauge, New York 11788  
**CANADA:** Audiovox Return Center, c/o Genco, 6685 Kennedy Road, Unit 3, Door 16, Mississauga, Ontario L5T 3A5


**CONSEJOS:** Cada tecla de dispositivo está asociada a un tipo de dispositivo—TV está configurada para buscar TV, SAT•CBL•DTC para receptores de satélite, aparatos de cable o convertidores de TV digital, y VCR•DVD para VCRs o lectores de DVD.

La tecla ON-OFF sirve de luz indicadora durante la programación, ofreciéndole retroalimentación en cada etapa del proceso.

El método de Búsqueda Manual de Códigos podría tomar más tiempo porque el control remoto busca a través de todos los códigos en su memoria uno por uno. Si su marca aparece en las Listas de Códigos por Marca o Listas de Códigos, intente primero la Búsqueda de Códigos por Marca o el método de Entrada Directa de Códigos.

Para salir en cualquier momento de la Búsqueda Manual de Códigos sin guardar un código nuevo, oprima la tecla GO BACK.


1. Encienda manualmente el dispositivo que desea manejar.




2. Si está programando la tecla TV o SAT•CBL•DTC, vaya al paso 3.

Si está programando la tecla VCR•DVD, necesitará indicarle al control remoto el tipo de dispositivo que desea que esta tecla maneje, VCR o Lector de DVD.

Oprima y sostenga la tecla VCR•DVD. Mientras sostiene la tecla VCR•DVD, utilice la otra mano para oprimir la tecla numérica para el tipo de dispositivo que desea manejar con esta tecla: 2 para VCR, 3 para Lector de DVD.




3. Oprima y sostenga la tecla de dispositivo que desea programar. A la vez que sostiene la tecla de dispositivo, utilice la otra mano para oprimir y sostener simultáneamente la tecla ON-OFF del control remoto.



4. Espere hasta que la tecla ON-OFF se ilumine y permanezca iluminada. Luego, suelte ambas teclas.

5. Mantenga el control remoto apuntado directamente al panel frontal del dispositivo que desea manejar. Oprima la tecla ON-OFF del control remoto y espere 2 segundos.



**¿Se apagó el dispositivo?**

**Sí:** Oprima la tecla STOP para guardar el código. ¡Listo! La tecla de dispositivo está programada.

**NO:** Oprima ON-OFF nuevamente. El control remoto prueba el próximo código para su dispositivo.

Continúe oprimiendo ON-OFF cada 2 segundos hasta que el dispositivo se encienda. Cuando se encienda, oprima STOP.

**CONSEJO:** Debido a la gran cantidad de códigos, quizás necesite oprimir la tecla ON-OFF varias veces—posiblemente cientos de veces.

## NOTAS

A través de la programación de cada tecla, mantenga el control remoto apuntado directamente al sensor infrarrojo del dispositivo que está programando con el control remoto.

Pruebe el control remoto con el dispositivo para asegurarse que la tecla de dispositivo esté programada con el código correcto y garantizar así su máxima funcionalidad. Si no puede utilizar alguna de las funciones, intente con otro código. Para obtener mayor información, consulte la sección “Cómo Probar el Código para Obtener Máxima Funcionalidad” a continuación.

Durante la Búsqueda Manual de Códigos, el control remoto ignora la opresión de teclas que no son parte de la búsqueda.

La búsqueda se detendrá luego de dos minutos (la tecla ON-OFF parpadea cuatro veces y se apaga, y se retiene el último código programado bajo la tecla de dispositivo).

La tecla ON-OFF parpadea cuatro veces y se apaga cuando el control remoto ha recorrido todos los códigos. El control remoto sale del método de Búsqueda Manual de Códigos. Si su dispositivo aún no se ha apagado, intente un método de búsqueda diferente.

## Cómo Probar el Código para Obtener Máxima Funcionalidad

1. Pruebe una variedad de funciones del dispositivo con el control remoto. Si no puede utilizar alguna de las funciones del dispositivo, vaya al próximo paso e intente un código diferente.

2. Repita el Método de Búsqueda Manual de Códigos desde el comienzo. Cuando haya encontrado el código que vuela a encender el dispositivo, no oprima la tecla STOP, con la cual quedaría guardado el mismo código. En vez, con la unidad apagada, continúe oprimiendo la tecla ON-OFF rápidamente hasta que la unidad se vuelva a encender.

3. Si se vuelve a encender la unidad, habrá encontrado otro código que puede manejar ese dispositivo. Oprima la tecla STOP.

4. Nuevamente, pruebe la funcionalidad de la tecla intentando controlar una variedad de funciones del dispositivo. Si el código que se ha almacenado controla la mayoría de las funciones del dispositivo, entonces habrá concluido la programación. Si el código guardado no brinda una máxima funcionalidad, intente otro código.

Las teclas CH y VOL tienen dos funciones: pueden actuar como teclas de navegación en los sistemas de menús y como controladores de canales y volumen fuera de los menús. Las teclas CH brindan además control de salto hacia delante y salto hacia atrás para lectores de DVD y DVR que respaldan esta funcionalidad.

GO BACK sale de la programación del control remoto; además, desempeña las mismas funciones que en los controles remotos originales.

La tecla INPUT y — (guion) tiene tres funciones: (1) alterna entre todas las fuentes de video conectadas al televisor; (2) cuando el control remoto se encuentra en el modo VCR, este botón alterna entre la entrada VCR y TV; (3) cuando ingresa directamente números de canales digitales, este botón le permite separar el número del canal principal del número del canal secundario (tal como 59.1).

## IMPORTANTE

Dado que este control remoto maneja más de un dispositivo, deberá primero “indicarle” al control remoto cuál dispositivo desea manejar. En otras palabras, si desea manejar el televisor, deberá primero oprimir la tecla TV para poner el control remoto en el Modo TV. El control remoto permanece en ese modo de dispositivo hasta que oprime una tecla de dispositivo diferente. Por ejemplo, si el control remoto se encuentra en el Modo TV y desea manejar el Lector de DVD, deberá oprimir la tecla VCR•DVD para cambiar los modos de dispositivo.

## Luz de fondo

La iluminación de fondo le ayuda a ver mejor las teclas del control remoto en la oscuridad. Puede encender y apagar la iluminación de fondo oprimiendo la tecla de luz de fondo ( ). La luz de fondo permanece encendida siempre y cuando se continúe oprimiendo teclas y se apaga seis segundos luego de la última opresión de una tecla. Una vez se apague la luz de fondo, puede volver a activarla oprimiendo cualquier tecla. Si la iluminación de fondo está encendida, y oprime la tecla de fondo, la luz de fondo se apagará.

## Cómo Lograr Acceso a las Guías y Menús de Dispositivos

Muchos dispositivos utilizan guías y menús en pantalla para ayudarle a navegar a través de sus funciones y programación. Aunque este control remoto quizás no logre acceso a todos los sistemas de guías o menús de cada modelo de dispositivo, si ofrece alguna funcionalidad de menús y guías.

Para utilizar el sistema de guías o menús en pantalla de un dispositivo, deberá primero poner el control remoto en el Modo Menú o Guía.

1. Asegúrese que sus dispositivos estén encendidos y que su televisor se encuentre establecido en una entrada de dispositivo correcta (utilice la tecla INPUT para alternar entre las entradas cuando se encuentre en el Modo TV).

2. Oprima la tecla de dispositivo cuyo menú desea accesar.

3. Para lograr acceso a los menús, oprima la tecla MENU. Para lograr acceso a las guías, oprima la tecla GUIDE. La tecla ON-OFF parpadea, lo cual indica que se encuentra en el Modo Menú o Guía.

4. Utilice las teclas VOL+/- y CH+/- para navegar a través de la guía o el sistema de menús en pantalla. Para seleccionar el elemento resaltado, oprima la tecla OK.

**CONSEJO:** Si el control remoto no responde, verifique que la tecla ON-OFF esté todavía parpadeando. La tecla ON-OFF desaparece al cabo de 20 segundos. Si esto sucede, sencillamente vuelva a oprimir la tecla MENU o GUIDE, y luego intente su selección.

## Cómo Salir del Modo Menú/Guía

El control remoto sale automáticamente del Modo Menú o Guía luego de 20 segundos de inactividad (no se oprime ninguna tecla). En esos momentos, el control remoto borra del televisor el menú desplegado.


Si desea salir del Modo Menú usted mismo, oprima la tecla de dispositivo correspondiente en el control remoto (TV, SAT•CBL•DTC, VCR•DVD). La tecla ON-OFF se apagará.

El modelo actual puede ser diferente al ilustrado

## Funciones Avanzadas

### Recuperación de Códigos

Una vez haya programado el control remoto para manejar sus dispositivos, se recomienda anotar los códigos para futura referencia. Si utilizó el método de Entrada Directa de Códigos, es muy sencillo. Simplemente encuentre los códigos que ingresó y anótelos en los recuadros a continuación. Si utilizó uno de los métodos de Búsqueda de Códigos para programar el control remoto o si utilizó el método de Entrada Directa pero no recuerda el código, necesitará recuperar el código de cinco dígitos de cada uno de los dispositivos. Recuperar y anotar el código real le ahorrará tiempo si alguna vez necesita volver a programar el control remoto (por ejemplo, si se pierde la programación cuando cambia las baterías). Si anota los códigos, puede utilizar el método de Entrada Directa para volver a programar el control remoto a fin de manejar otros dispositivos, un proceso rápido y sencillo.



1. Oprima y sostenga la tecla de dispositivo (TV, SAT•CBL•DTC, VCR•DVD) cuyo código desea recuperar. La tecla ON-OFF se encenderá. Continúe oprimiendo la tecla de dispositivo.

2. Mientras sostiene la tecla de dispositivo, oprima y sostenga la tecla INFO. La tecla ON-OFF se apagará. Luego de sostener ambas teclas durante tres segundos, la tecla ON-OFF se encenderá nuevamente.

3. Suelte ambas teclas. La tecla ON-OFF permanece encendida.

4. Comenzando con la tecla numérica 1, oprima y suelte cada tecla numérica en el teclado en el siguiente orden 1-9, luego 0. El número que hace que la tecla ON-OFF parpadee es el primer número del código. Una vez se apague la luz de fondo, puede volver a activarla oprimiendo cualquier tecla. Si la iluminación de fondo está encendida, y oprime la tecla de fondo, la luz de fondo se apagará.

## Cómo Lograr Acceso a las Guías y Menús de Dispositivos

Muchos dispositivos utilizan guías y menús en pantalla para ayudarle a navegar a través de sus funciones y programación. Aunque este control remoto quizás no logre acceso a todos los sistemas de guías o menús de cada modelo de dispositivo, si ofrece alguna funcionalidad de menús y guías.

Para utilizar el sistema de guías o menús en pantalla de un dispositivo, deberá primero poner el control remoto en el Modo Menú o Guía.

1. Asegúrese que sus dispositivos estén encendidos y que su televisor se encuentre establecido en una entrada de dispositivo correcta (utilice la tecla INPUT para alternar entre las entradas cuando se encuentre en el Modo TV).

2. Oprima la tecla de dispositivo cuyo menú desea accesar.

3. Para lograr acceso a los menús, oprima la tecla MENU. Para lograr acceso a las guías, oprima la tecla GUIDE. La tecla ON-OFF parpadea, lo cual indica que se encuentra en el Modo Menú o Guía.

4. Utilice las teclas VOL+/- y CH+/- para navegar a través de la guía o el sistema de menús en pantalla. Para seleccionar el elemento resaltado, oprima la tecla OK.

**CONSEJO:** Si el control remoto no responde, verifique que la tecla ON-OFF esté todavía parpadeando. La tecla ON-OFF desaparece al cabo de 20 segundos. Si esto sucede, sencillamente vuelva a oprimir la tecla MENU o GUIDE, y luego intente su selección.

## Cómo Salir del Modo Menú/Guía

El control remoto sale automáticamente del Modo Menú o Guía luego de 20 segundos de inactividad (no se oprime ninguna tecla). En esos momentos, el control remoto borra del televisor el menú desplegado.

Si desea salir del Modo Menú usted mismo, oprima la tecla de dispositivo correspondiente en el control remoto (TV, SAT•CBL•DTC, VCR•DVD). La tecla ON-OFF se apagará.

**Problema: El control remoto no cambia canales en el dispositivo.**

• Asegúrese que el control remoto se encuentre en el modo correcto oprimiendo la tecla de dispositivo correspondiente (TV, SAT•CBL•DTC, VCR•DVD). Esto le indica al control remoto el dispositivo que debe manejar.

• Oprima la tecla ENTER luego de haber ingresado un número de canal.

• Retire los obstáculos ubicados entre el control remoto y el dispositivo. Asegúrese de apuntar el control remoto directamente al sensor infrarrojo del dispositivo.

• Asegúrese que las baterías estén cargadas y debidamente instaladas. Reemplace las baterías con dos baterías AA nuevas, de ser necesario (consulte la sección Instalación de las Baterías).

**Problema: El control remoto no maneja su dispositivo.**

• Asegúrese que el control remoto se encuentre en el modo correcto oprimiendo la tecla de dispositivo correspondiente (TV, SAT•CBL•DTC, VCR•DVD). Esto le indica al control remoto el dispositivo que debe manejar.

• El acceso a los menús no es respaldado por todas las marcas. Posiblemente sea necesario utilizar el control remoto original para lograr acceso a las funciones de menú de algunos dispositivos.

**Para obtener mayor información, visite**  
[www.rcaaccessories.com](http://www.rcaaccessories.com)

**Línea de Ayuda para el Cliente:** 1-800-420-7968

## Cuidado y Mantenimiento

• Mantenga el control remoto seco. Si se moja, séquelo inmediatamente.

• Utilice y almáocene el control remoto únicamente en entornos de temperatura normal.

• Maneje el control remoto de forma cuidadosa. No lo deje caer.

• Mantenga el control remoto resguardado del polvo y la suciedad.

• Limpie el control remoto con un paño húmedo de vez en cuando para mantenerlo en buenas condiciones de operación.

• Modificar o sabotear los dispositivos internos del control remoto podría ocasionar desperfectos y anular la garantía.

## Garantía Limitada Durante la Vida Útil del Producto

Audiovox Electronics Corporation (la “Compañía”) le garantiza a usted, el comprador original de este producto que si, bajo condiciones y uso normales, se encontrara que presenta defectos materiales o de mano de obra durante su vida útil mientras sea de su propiedad, tales defectos serán reparados o reemplazados (la opción de la Compañía) sin cargo alguno por las piezas y labores de reparación. Para obtener los servicios de reparación o reemplazo dentro de los términos de esta Garantía, el producto se entregará con prueba de cubierta de garantía (por ejemplo, factura fechada de venta, especificación de los defectos, transporte prepago), a la Compañía a la dirección indicada abajo.

Esta Garantía no cubre un producto adquirido, mantenido o utilizado fuera de los Estados Unidos o Canadá. Esta Garantía no es transferible y no incluye los costos incurridos en la instalación, remoción o reinstalación de este producto. Esta Garantía no aplica si, es opinión de la Compañía que, este producto ha sufrido daños debido a alteraciones, instalación inadecuada, abuso, uso indebido, negligencia, accidente o el uso simultáneo de diferentes tipos de baterías (por ejemplo, alcalinas, tópicas o recargables). EL ALCANCE DE LA RESPONSABILIDAD DE LA COMPAÑÍA BAJO ESTA GARANTÍA ESTÁ LIMITADO A LA REPARACIÓN O EL REEMPLAZO PROVISTO ARRIBA Y, EN NINGÚN CASO, DEBERÁ LA RESPONSABILIDAD DE LA COMPAÑÍA EXCEDER EL PRECIO DE COMPRA PAGADO POR EL COMPRADOR DE ESTE PRODUCTO.

Esta Garantía reemplaza cualesquier otras responsabilidades o garantías expresas. CUALESQUIERA GARANTÍAS IMPLÍCITAS, INCLUYENDO CUALQUIER GARANTÍA IMPLÍCITA DE COMERCIALIZAD O ADAPTABILIDAD PARA UN PROPÓSITO EN PARTICULAR ESTARÁN LIMITADAS A LA DURACIÓN DE ESTA GARANTÍA. EN NINGUN CASO LA COMPAÑÍA SERÁ RESPONSABLE POR DAÑOS EMERGENTES O INCIDENTALES. Ninguna persona ni representante está autorizado a asumir, a nombre de la Compañía, ninguna responsabilidad salvo la expresada aquí en conexión con la venta de este producto. Algunos estados/provincias no permiten limitaciones sobre la duración de una garantía implícita o la exclusión o la limitación de daños incidentales o emergentes, de modo que es posible que las limitaciones o exclusiones anteriores no apliquen en su caso. Esta Garantía le confiere derechos legales específicos; según el estado/provincia, puede disfrutar además de otros derechos.

**EE.UU.:** Audiovox Electronics Corporation, 150 Marcus Blvd., Hauppauge, New York 11788  
**CANADÁ:** Audiovox Return Center, c/o Genco, 6685 Kennedy Road, Unit 3, Door 16, Mississauga, Ontario L5T 3A5