

**FCC statement**

Note : This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution :** Changes or modifications not expressly approved by VOXX Accessories Corporation could void the user's authority to operate the equipment.

**Industry of Canada regulatory information**

CAN ICES-3 (B)/NMB-3 (B)

**Avis d'Industrie Canada**

CAN ICES-3 (B)/NMB-3 (B)

**Battery Installation**

Your RCR504BE / CRCR504BE universal remote requires 2 new AAA alkaline batteries (sold separately).

**To install the batteries:**

1. Turn the unit over, and remove the battery compartment cover.
2. Insert the batteries, matching the batteries to the (+) and (-) marks inside the battery case.

**Battery Precautions:**

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Always remove old, weak or worn-out batteries promptly and recycle or dispose of them in accordance with Local and National Regulations.

**Programming with Direct Entry**

To program your remote to control up to four components, follow these steps:

1. Manually turn on the component you wish to program the remote to operate.
2. Find the four-digit code for your brand of TV, VCR, DVD, satellite receiver, cable box, or digital TV converter in the enclosed code lists.
3. Press and hold the **CODE SEARCH** key until the indicator light turns off.
4. Release the **CODE SEARCH** key.
5. Press and release the **ON-OFF** key until the component turns off.
6. As soon as the component turns off, press the **ENTER** key within 4 seconds. The indicator light turns off.

**Note:** If you wait longer than 4 seconds to press **ENTER**, the remote goes to the next code—you will need to start the code search from step 1 again.

**CODE SEARCH****INDICATOR LIGHT****(OFF)****Programming with Direct Entry**

4. Release the **CODE SEARCH** key.
5. Press and release the **TV, VCR** or **SAT-CBL-DTC** key. The indicator light blinks and then remains lit.
- Note:** DTC references digital TV converter.

To program the **DVD-AUX** key: Press the **DVD-AUX** key. To control a DVD, press the **VCR** key. To control a TV, press the **TV** key. To control a satellite receiver, cable box, or digital TV converter, press the **SAT-CBL-DTC** key. The indicator light stops blinking and remains lit.

6. Enter the four-digit code, using the numeric keypad. After the code is entered, the indicator light turns off.

**Note:** If the indicator light blinks multiple times, you've entered an invalid code. Start from step 2 again.

7. Aim the remote at the component and press the **ON-OFF** key. The component should turn off.

**Note:** If your component does not respond, try all the codes for your brands. If the codes do not work or your brand is not listed, try the Code Search Method that follows.

8. Aim the remote at the component and press the **ON-OFF** key. The component should turn off.

**Note:** If your component does not respond, try all the codes for your brands. If the codes do not work or your brand is not listed, try the Code Search Method that follows.

9. While in Menu Mode, these keys function as follows:

| Mode            | Vol up/down             | Ch +/-               |
|-----------------|-------------------------|----------------------|
| TV, SAT-CBL-DTC | Cursor moves right/left | Cursor moves up/down |
| VCR, DVD        |                         |                      |
| ON-OFF          |                         |                      |
| (OFF)           |                         |                      |

**ON-OFF**

**(OFF)**

**Menu Function – TV, VCR, DVD, SAT•CBL•DTC**

The Menu function on your remote is used to make changes on selected settings. The **MENU** key operates in TV, VCR, DVD and SAT•CBL•DTC Modes. Each menu varies from brand to brand.

The TV Menu is used to make changes in the TV settings, such as changing color, channels and timers. The SAT•CBL•DTC Menu navigates through the Menu screens to make changes to settings. The VCR or DVD Menu you can navigate to languages, subtitles and more.

While in Menu Mode, these keys function as follows:

| Mode            | Vol up/down             | Ch +/-               |
|-----------------|-------------------------|----------------------|
| TV, SAT-CBL-DTC | Cursor moves right/left | Cursor moves up/down |
| VCR, DVD        |                         |                      |
| ON-OFF          |                         |                      |
| (OFF)           |                         |                      |

**ON-OFF**

**(OFF)**

**90 Day Limited Warranty**

Su control remoto universal RCR504BE / CRCR504BE requiere de 2 baterías alcalinas AAA nuevas (se venden por separado).

Presione la tecla **MENU**. Aparece el menú del componente seleccionado.

Para instalar las baterías:

1. Voltee la unidad, y quite la tapa del compartimiento de baterías.

**Nota:** Quizás todas las marcas no funcionen completamente.

2. Introduzca las baterías, cuidando que el (+) y el (-) de las baterías sean iguales a las marcas dentro del compartimiento de las baterías.

3. Para salir del modo menú, presione la tecla correspondiente en el control remoto (**TV, VCR, DVD-AUX o SAT-CBL-DTC**).

**Precauciones sobre las baterías:**

• No combine baterías nuevas y viejas.

• No combine diferentes tipos de baterías: alcalinas, estándar (carbono-zinc) o recargables (niquel-cadmio).

• Siempre remueva de inmediato baterías viejas, débiles o desgastadas, y recíclelas según lo dispone las normas locales y nacionales.

EL ALCANCE DE LA RESPONSABILIDAD DE LA COMPAÑIA BAJO ESTA GARANTÍA ESTÁ LIMITADO A LA REPARACIÓN O EL REEMPLAZO PROVISTO ARRIBA Y, EN NINGUN CASO, DEBERÁ LA RESPONSABILIDAD DE LA COMPAÑIA EXCEDER EL PRECIO DE COMPRA PAGADO POR EL COMPRADOR DE ESTE PRODUCTO.

Esta Garantía reemplaza cualesquier otras responsabilidades o garantías expresas.

2. Presione la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

3. Luego suelte la tecla **CODE SEARCH**.

4. Presione y suelte la tecla del componente que usted desea controlar – tecla de la **TV, VCR o SAT-CBL-DTC**. La luz del indicador debe parpadea una vez y permanecer prendida.

5. Presione y suelte la tecla **CODE SEARCH**.

6. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

7. Luego suelte la tecla **CODE SEARCH**.

8. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

9. Luego suelte la tecla **CODE SEARCH**.

10. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

11. Luego suelte la tecla **CODE SEARCH**.

12. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

13. Luego suelte la tecla **CODE SEARCH**.

14. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

15. Luego suelte la tecla **CODE SEARCH**.

16. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

17. Luego suelte la tecla **CODE SEARCH**.

18. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

19. Luego suelte la tecla **CODE SEARCH**.

20. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

21. Luego suelte la tecla **CODE SEARCH**.

22. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

23. Luego suelte la tecla **CODE SEARCH**.

24. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

25. Luego suelte la tecla **CODE SEARCH**.

26. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

27. Luego suelte la tecla **CODE SEARCH**.

28. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

29. Luego suelte la tecla **CODE SEARCH**.

30. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

31. Luego suelte la tecla **CODE SEARCH**.

32. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

33. Luego suelte la tecla **CODE SEARCH**.

34. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

35. Luego suelte la tecla **CODE SEARCH**.

36. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

37. Luego suelte la tecla **CODE SEARCH**.

38. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

39. Luego suelte la tecla **CODE SEARCH**.

40. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

41. Luego suelte la tecla **CODE SEARCH**.

42. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

43. Luego suelte la tecla **CODE SEARCH**.

44. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

45. Luego suelte la tecla **CODE SEARCH**.

46. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

47. Luego suelte la tecla **CODE SEARCH**.

48. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

49. Luego suelte la tecla **CODE SEARCH**.

50. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

51. Luego suelte la tecla **CODE SEARCH**.

52. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

53. Luego suelte la tecla **CODE SEARCH**.

54. Presione y suelte la tecla **CODE SEARCH** (búsqueda de códigos) hasta que se ilumine el indicador.

55. Luego suel

