CAR[®]LINK[™] owner's card

	C START	This button will send a START command to your previously installed remote starter. The vehicles engine will start and run for the preset time. The timer will begin to count down from the preset runtime set by your installer.
	STOP	This button will send a STOP command to your vehicles remote starter. The vehicle's engine will shut down and the runtime status will change to 00:00:00 once the action has been completed.
	C LOCK	This button will LOCK and/or ARM your vehicle. Your vehicle MUST be equipped with a power door lock system for this feature to work. The door lock status will change once this action is completed.
C 00:00:00 START O 00:00:00	GUNLOCK	This button will UNLOCK and/or DISARM your vehicle. Your vehicle MUST be equipped with a power door locking system for this feature to work. The door unlock status will change once this action is completed.
LOCK DOORS ARE UNLOCK		his icon will display if CL6 is connected to the network (GREEN) or not (GREY).
COCATE VEHICLE	12.0	his icon will display the vehicle's battery level.

This button will allow you to see your current vehicle location.

0

へ

This button will allow you to access the AUXILIARY functions. Some of the functions could be Motorized Lift Gate, Trunk Release, Power Sliding Doors, Rear Defrost, ETC. See your retailer for more details.

For more detailed instructions, please consult the HELP section of the CL6 App.

How to Activate Your New

CAR[®]LINK

Product Sticker Here

Step 1: App & Account Setup

- 1. Start by downloading the CL6 smartphone app.
- 2. Once completed, Launch the CL6 app on your device.
- 3. Click the "Create an Account" and fill in all of the required fields then click the "Create your Account".
- 4. Open your email and look for a new email from "MYCARCONTROLS"
- 5. To activate your account and create your password, click on the link in the email.
- 6. Create your secure password and activate your account
- 7. Once done, log into the app using your email address and new secure password.

Step 2: Add A Device/Vehicle

- 1. Click on the (+) sign in the bottom right corner of the "My Cars" screen to add your device/vehicle to your
- 2. Eff@#ffe 16 digit "Serial Number" found in the upper right hand corner of this document. (SN:XXXXX-XXXXXXXXXXX)
- 3. Click the "Submit the Code".



CL6 App