

CHRADKIT
2009-2010 VW ROUTAN
2008-2010 CHRYSLER TOWN AND
COUNTRY/DODGE CARAVAN
OVERHEAD VIDEO MOUNTING KIT



INSTALLATION INSTRUCTIONS FOR MODELS
VOD85, 86, 102, 100
ADV25, 26, 35, 30
JMV85

128-6896 rev b

THESE INSTRUCTIONS ARE INTENDED FOR USE BY EXPERIENCED PROFESSIONALS IN THE AUTOMOTIVE CUSTOMIZING FIELD. SPECIAL TOOLS AND EQUIPMENT, AS WELL AS SPECIALIZED HANDLING AND CARE OF PRODUCT DURING INSTALLATION MAY BE REQUIRED. BEFORE BEGINNING THE INSTALLATION, CAREFULLY READ THE FOLLOWING INSTRUCTIONS.

CAUTION: USE EXTREME CARE WHEN CUTTING THE HEADLINER MATERIAL OR DRILLING HOLES. CHECK FOR WIRING AND OTHER COMPONENTS THAT MAY BE LOCATED ABOVE THE HEADLINER. CUT ONLY WHERE INDICATED. DO NOT INTERFERE WITH THE DEPLOYMENT PATH OF THE SIDE CURTAIN AIRBAGS.

MATERIALS/TOOLS REQUIRED FOR THIS INSTALLATION:

- | | |
|-----------------------|------------------------|
| 1. PLASTIC PRY TOOL | 6. RATCHET |
| 2. WIRE STRIPPERS | 7. ELECTRICAL TAPE |
| 3. 7MM SOCKET | 8. POWERED SCREWDRIVER |
| 4. DIGITAL VOLT METER | 9. #2 PHILLIPS ADAPTOR |
| 5. MARKER | 10. DRILLBITS |

MATERIALS PROVIDED:

ITEM	DESCRIPTION	QTY
1.	MAIN BRACKET	1
2.	SHALE RUBBER GASKET	1
3.	PEWTER RUBBER GASKET	1
4.	M5 x 12MM SCREWS	4
5.	INSTALLATION INSTRUCTIONS	1
6.	DOUBLE SIDED TAPE	1

- FLIP OPEN THE FORWARD MOST STORAGE COMPARTMENT LOCATED ON THE FULL LENGTH OVERHEAD CONSOLE.



- USING A PRY TOOL, PRY OUT THE STORAGE POCKET HINGE PIN. DISCONNECT THE STORAGE COMPARTMENT FROM THE CONSOLE.



- DRILL A HOLE IN THE CONSOLE FOR THE OVERHEAD WIRING. PLEASE REFER TO THE VIDEO SYSTEM INSTALLATION MANUAL.



- REMOVE THE FOUR (4) FACTORY FASTENERS



- INSTALL NEW MOUNTING BRACKET BY REINSTALLING THE FOUR (4) PREVIOUSLY REMOVED FASTNERS



- ATTACH THE APPROPRIATE COLOR, RUBBER GASKET (SUPPLIED) TO THE VIDEO MONITOR USING THE SCREWS THAT ARE PROVIDED WITH MONITOR. PLEASE REFER TO THE VIDEO MONITOR INSTALLATION GUIDE.



- APPLY THE SUPPLIED DOUBLE SIDED TAPE TO THE RUBBER GASKET AS SHOWN IN THE BELOW PICTURE.



- CONNECT PREVIOUSLY INSTALLED WIRING TO THE NEW VIDEO MONITOR. RAISE THE VIDEO MONITOR ASSEMBLY UP TO THE PREVIOUSLY INSTALLED BRACKET AND FASTEN IT USING THE SUPPLIED FOUR (4) M5 SCREWS.



- USING THE OWNER'S MANUALS FOR THE VEHICLE AND NEW MONITOR, VERIFY THAT THE VEHICLE AND THE MONITOR ARE FUNCTIONING CORRECTLY.