

**Caution: Unplug AC line cords from both components you wish to connect.**

## How to connect

1. Connect one set of plugs to the audio output jacks on your audio source.
2. Connect the other set of plugs to the audio input jacks on your TV, HDTV or A/V receiver.


**Important: Match the colors on the plugs with the colors on the jacks—red to red and white to white.**

**Precaución: Desenchufe los cordones de línea de CA de ambos componentes que desea conectar.**

## Cómo conectar

1. Acople un juego de enchufes a los conectores de salida de audio de la fuente de audio.
2. Acople el otro juego de enchufes a los conectores de entrada de audio del TV, HDTV o receptor de A/V.

**Importante: Aparee los colores en los enchufes—rojo a rojo y blanco a blanco.**



## Lifetime Warranty

Audiovox Electronics Corporation will replace this product, regardless of how long you own it, if it should fail to perform to its design specifications. Simply return to the following address for a replacement: Audiovox Electronics Corporation, 150 Marcus Blvd., Hauppauge, New York 11788.

## Garantía por Vida

Audiovox Electronics Corporation reemplazará este producto, independientemente de por cuánto tiempo Ud. lo haya poseído, si se encontrara que el producto no funciona según las especificaciones. Sencillamente devuélvalo a la siguiente dirección para obtener un reemplazo: Audiovox Electronics Corporation, 150 Marcus Blvd., Hauppauge, New York 11788.