



portable wireless speaker
customize with  skinit®

quick start guide

Congratulations on your purchase of the Acoustic Research portable wireless speaker! This speaker makes it easy to take your music wherever you go and share it whenever you want, with Bluetooth® wireless connectivity and a built-in auxiliary input.

A free skin from Skinit lets you make this speaker truly your own, with thousands of designs to choose from, including professional and college sports teams, popular entertainment and social icons, even your own photo or design.

This Quick Start Guide gets you started in 3 easy steps:

- 1 Set Up the Wireless Speaker**
- 2 Order Your Free Speaker Skin**
- 3 Apply the Skin to Your Wireless Speaker**


IMPORTANT: Make sure you test this speaker with your smartphone or other audio device **BEFORE** you order your free skin!

What's a skin? A skin is a durable vinyl sticker with a design of your choice printed on it that you apply to your speaker. The sticker is easy to put on and take off, with no residue left on the speaker itself.

1. Set Up the Wireless Speaker

Unpack

Make sure the following items came in this package.



Portable
Wireless
Speaker




AC Adapter

Skinit
Redemption
Card




User Guide




Power the Speaker

The portable wireless speaker can be powered using either the AC adapter in this package or using 6 AA batteries (not supplied).


Using the AC adapter



Using Batteries




AA x 6



Turn the Speaker On


Press and hold the  button until the indicator light on the front of the speaker starts blinking slowly (blue).




Pair and Connect




Enable Bluetooth on your device (smartphone, MP3 player, tablet, etc.).



Press and hold the **Pair** button on the top of the speaker for 3 seconds (the blue light blinks faster).



Choose "AWSBT1" on your device.



The speaker light turns solid blue when you're connected.

Play Music




Turn your device's volume for music up to at least 75% max.



Start playing music or other audio on your device. Within seconds, the speaker starts streaming the audio wirelessly via Bluetooth.

To adjust the volume of your audio, use the **Volume +** and **-** buttons on the top of the speaker.



If you notice the sound is distorting even at low volumes, turn the volume down on your device.

2. Order Your Free Skin

Go to www.Skinit.com/SportSpeaker



This is where you redeem the special offer card that came with your package, with thousands of designs made just for the AR portable wireless speaker, from college and pro sports teams to popular social and entertainment icons.

Enter the Pincode from the Skinit card

Find the Skinit redemption card among the items included in your packaging. Turn it over and locate the Pincode at the bottom of the card.

Enter this number in the **Redeem** box on the www.Skinit.com/SportSpeaker page and click on the arrow icon.

Skinit offer card

Skinit.com/SportSpeaker page

Find or create the skin you want

Skinit offers two ways to get the skin you want: choose from their vast library of existing designs or create a customized skin from a photo or design of your own.

To use one of the thousands of designs from the Skinit library available for this speaker: browse through the design categories to find the team, school, movie, character, or other design option you want.

To create your own skin from a photo or design: click on the **CREATE YOUR OWN** button at the top of the designs page. Then follow the on-screen directions to upload your photo or design and create your customized skin.

Add the skin to your cart

Once you've found the skin you want for your speaker (or finished creating your customized skin), click on **Add to cart** to put it in your shopping cart.

Check out

Once you've reviewed the details for your skin in the shopping cart, click on the **Checkout** button at the bottom of the page.

Enter your address and place the order


The next screen will ask for your mailing address and an email where Skinit.com can send you confirmation and tracking information for your order. If the mailing address is in the United States or Canada, standard shipping for your skin is free! (Additional charges may apply for other locations.)

Once you've entered your address, click on the **Continue** button to process your order. The final screen gives you an overview of your order. Check it one last time; if everything's correct, click on the **Place Order** button.

US and Canadian orders should receive a skin within a week. Other locations may take longer.


3. Apply the Skin

Remove the speaker's back cover




The skin is designed to go on the speaker's back cover. It's easier to apply the skin when the back cover is off the speaker. To remove this cover, lift the latch at its bottom.

Clean the speaker's back cover



Use a soft, dry cloth to clean any dust or particles from the surface of the speaker's back cover.


Peel the skin from its backing



Gently remove the skin from its backing.

Note: Save the backing—you can use it to store the skin if you ever need to take it off.

Apply the skin to the speaker's back cover



Place the slot at the bottom of the skin directly over the latch at the bottom of the back cover (as shown here).



Push up on the middle of the skin to apply it to the middle of the back cover (as shown here).



Press out from the middle of the skin toward the edges (as shown here). Use the base of your palm to press out any bubbles.

IMPORTANT: This skin was designed to be as easy to take off as it is to put on the speaker. So, if you notice that you didn't apply the skin exactly the way you wanted, or if you want to replace this skin with another one in the future, don't worry: simply pull back a corner of the skin and peel it slowly off the speaker.