

Quick Setup Guide

A built-in automatic time set system is equipped in this clock. Follow the instructions below to get the clock time to show correctly:

1. Plug for power

Insert the plug of the unit into an AC power outlet.



2. Select daylight saving

If your region is currently observing Daylight Savings Time, then position the switch to **ON**.

This switch offers a simple way to change the clock time in the spring or fall when Daylight Savings starts or ends.



3. Select your time zone

Press **TIME ZONE** repeatedly at the back of the unit to cycle through the time zones.

Time Zone

EST	Eastern (default)	←
↓		
CST	Central	
↓		
MST	Mountain	
↓		
PST	Pacific	
↓		
AKST	Alaskan	
↓		
HST	Hawaii-Aleutian	
↓		
AST	Atlantic	



Your clock is now set and ready for use.