

## TV Codes / Códigos de TV

Admiral.....	0093, 0463	Matsushita.....	0250
Advent.....	0761	Maxent.....	1755
Akai.....	0812, 1675, 0702, 1935	MB Quart.....	1868
AOC.....	1365, 1589, 2014, 2087, 2479	Megatron.....	0178, 0145
Apex Digital.....	0748, 0765, 1217, 2397	Memorex.....	0463, 0150, 0178, 1670, 1892
Audiovox.....	0451, 0802, 1766,	MGA.....	0150, 0178
.....	1769, 1868, 2121	Midland.....	0000, 0017, 0051
Aventura.....	0171	Mitsubishi.....	1250, 0093, 0150, 0178
Broksonic.....	0463, 1935	Motorola.....	0093
Carver.....	0054	MTC.....	0060
Celebrity.....	0001	NAD.....	0156, 0178
Celera.....	0765	NEC.....	1797
Changhong.....	0765	NetTV.....	1755
Citizen.....	0060, 1935	Nexus Electronics.....	2183
Coby ..	1634, 2306, 2315, 2344, 2345, 2348	Nikko.....	0178
Commercial Solutions.....	1447, 0000	Norcent.....	0748, 1365, 1589
Crosley.....	0001, 0054	Olevia.....	1610, 1240, 1331
Curtis.....	2352, 2466	Optimus.....	0250
Curtis Mathes.....	0000, 0054, 0451, 0093,	Optoma.....	1348
.....	0060, 0702, 0145, 1661	Optonica.....	0093
Daewoo.....	0451, 1661	Orion.....	0463, 1463
Dell.....	1264	Panasonic.....	1480, 0250, 1457,
Denon.....	0145	.....	0051, 1291, 2264
Dumont.....	0017	PARK.....	2104, 2194
Durabrand.....	0463, 0178, 0171	Penney.....	0000, 0156, 0051, 0060, 0178
Dynex.....	1463, 2049, 2184	Petters.....	1523
Electroband.....	0001	Philco.....	0054, 0171, 1394, 1665, 1963
Electrograph.....	1755	Philips.....	1454, 1866, 0054, 1744,
Electrohome.....	0463, 1670	.....	1856, 2372, 2374
Element.....	1687, 1886, 2183	Pioneer.....	1457
Emerson.....	1864, 0451, 0463, 0178,	Polaroid.....	1523, 0765, 1276, 1498,
.....	0171, 1661, 1394, 1665, 1963	.....	1687, 1766, 1769, 2121
Emprex.....	1422	Portland.....	0451, 1661
Envision.....	1365, 1589, 2014, 2087	Prima.....	0761
ESA.....	0812, 0171, 1963	Prism.....	0051
Funai.....	0001, 0171, 1963	Proscan.....	1447, 0000, 2256
Gateway.....	1755	Proton.....	0178
GE.....	1547, 1447, 0000, 0051, 0451, 0178	Proview.....	1498, 1687
GFM.....	0171, 1665, 1963, 2167	Pulsar.....	0017
Gibraltar.....	0017	Quasar.....	0250, 0051
GoldStar.....	0178	RadioShack.....	0000, 0178
Haier.....	1748, 1749, 2309	RCA.....	1547, 1447, 0000, 0051, 0093,
Hallmark.....	0178	.....	1661, 1781, 2187, 2247, 2434
Hannspree.....	1348	Realistic.....	0178
Harman/Kardon.....	0054	Runco.....	0017
Havermy.....	0093	Sampo.....	1755
Hello Kitty.....	0451	Samsung.....	0812, 0060, 0702,
Hisense.....	0748, 1660, 2098, 2355	.....	0178, 1060, 2051
Hitachi.....	1643, 0145	Sansui.....	0463, 0171, 1670, 1892, 1935
iLo.....	1394, 1665, 1684	Sanyo.....	0054, 1142
Infinity.....	0054	Sceptre.....	0878, 1217, 1360, 1599, 2506
Insignia.....	1423, 1564, 0463, 0171,	Scotch.....	0178
.....	1660, 1710, 1892, 1963, 2049	Scott.....	0178, 1711
Inteq.....	0017	Sears.....	0000, 0054, 0156, 0178, 0171
JBL.....	0054	Sharp.....	0818, 0093
JCB.....	0001	Sheng Chia.....	0093
Jensen.....	0761	Signature.....	0054
JVC.....	0463, 0053, 1253, 1601, 1774, 2264	Sony.....	0810, 0001
KDS.....	1498, 1687	Soundesign.....	0178
KLH.....	0765	Soyo.....	1826
LG.....	1423, 1447, 0017, 0178, 2358, 2424	Spectroniq.....	1498, 1687
LXI.....	0000, 0054, 0156, 0178	Squareview.....	0171
MAG.....	1498, 1687	Superscan.....	0093
Magnavox.....	1454, 1866, 1755, 0054, 0051,	Supreme.....	0001
.....	0171, 0802, 1365, 1856, 1963, 2372	SVX.....	0748, 1963
Marantz.....	1454, 0054	Sylvania.....	1864, 0054, 0171,

.....	1394, 1665, 1886, 1963	Vidtech.....	0178
Symphonic.....	0171	Viewsonic.....	1755, 0885, 1330, 1365, 1578,
Syntax.....	1610, 1240, 1331	.....	1627, 1640, 1742, 2014, 2087, 2277
Tandy.....	0093	Viore.....	1684, 2104, 2352
Technics.....	0250, 0051	Vizio.....	1758, 0885
Techwood.....	0051	Wards.....	0001, 0000, 0054, 0017, 0156,
Teknika.....	0054, 0150, 0060	.....	0051, 0060, 0178
Telefunken.....	0702	Waycon.....	0156
TMK.....	0178	Westinghouse.....	1712, 0451, 0885, 1217
TNCl.....	0017	White Westinghouse.....	0463, 1661
Toshiba1524, 0156, 0060, 1291, 1935, 2006		Wyse.....	1365
TVS.....	0463	Zenith.....	0001, 1423, 0000, 0017,
Victor.....	0053	.....	0463, 0178, 0145, 1661, 1365
Vidikron.....	0054		

## Cable Codes / Códigos de Cable

Amino.....	1602, 1822	Pace.....	1376, 1877, 1982
Bright House.....	1376, 1877	Panasonic.....	1982
Cable One.....	1376, 1877	Pioneer.....	1877
Cablevision.....	1376, 1877, 1006	RCA.....	1256
Charter.....	1376, 1877, 2187	Rogers.....	1877
Cisco.....	1877, 1982	Scientific Atlanta.....	1877
Comcast.....	1376, 1877, 1982, 2576	Sejin.....	1602
Cox.....	1376, 1877	Shaw.....	1376
Digeo.....	1187, 2187	Sony.....	1006
i3 Micro.....	1602	Suddenlink.....	1376, 1877
Insight.....	1376, 1877	Thomson.....	1256, 1982
Knology.....	1877	Time Warner.....	1376, 1877, 2187
Mediacom.....	1376, 1877	Tivo.....	2576
Motorola.....	1376, 1187, 1982	WideOpenWest.....	1877
Myrio.....	1602, 1822		

## Satellite Codes / Códigos de Satélite

Bell ExpressVu.....	0775	Mitsubishi.....	0749
DirecTV.....	1377, 0392, 0000, 0639,	Motorola.....	0869, 0856
.....	1142, 0749, 1749, 0819, 1076	Next Level.....	0869
Dish Network.....	0775, 1505	Panasonic.....	0701
Dishpro.....	0775, 1505	Philips.....	1142, 0749, 1749, 1076
Echostar.....	0775, 1505	Proscan.....	0392, 0000
Expressvu.....	0775	RadioShack.....	0869
GE.....	0000	RCA.....	0392, 0000, 0143
General Instrument.....	0869	Samsung.....	1377
GOI.....	0775	Sony.....	0639
Hitachi.....	0819	Star Choice.....	0869
HTS.....	0775	Tivo.....	1142
Hughes Network Systems.....	1142, 0749, 1749	Toshiba.....	0749, 1749, 0790
Jerrold.....	0869	Voom.....	0869
JVC.....	0775		

## Video Accessories Codes / Códigos de Accesorios de vídeo

Access HD.....	2185	Insignia.....	1415
ADB.....	2254	KoolConnect.....	1481
Airlink 101.....	2491	Lasonic.....	2348
Alpha Digital.....	2185	LG.....	1415
Amino.....	1481, 1615, 2482	Magnavox.....	1563
AMTC.....	2185	Memorex.....	2486
Apex Digital.....	2478	MicroGEM.....	2489
Artec.....	2490	Motorola.....	0858, 2378
AT&T.....	0858	Philco.....	1563
CASTI.....	2305	RCA.....	2325, 2454
Channel Master.....	2365	Sansonic.....	2348
Cisco.....	2345	Scientific Atlanta.....	0858, 2345
Coby.....	2667	Sunkey.....	2695
Coship.....	2487	SureWest.....	1481
Daewoo.....	2338	Sylvania.....	1563
Daytek.....	2305	Tivax.....	2185
Digital Stream.....	2303	Ventura.....	2454
Dish Network.....	2470	Venturer.....	2454
Echostar.....	2470	Verizon.....	2378
Epson.....	1563	Winegard.....	2454
GE.....	2360, 2450	Zenith.....	1415
Goodmind.....	2450	Zentech.....	2491
Gridlink.....	2348	Zinwell.....	2488

## Digital TV Converter Boxes / Digital TV Converter Boxes

Access HD.....	2185	Insignia.....	1415
Airlink 101.....	2491	Lasonic.....	2348
Alpha Digital.....	2185	Magnavox.....	1563
AMTC.....	2185	Memorex.....	2486
Apex Digital.....	2478	MicroGEM.....	2489
Artec.....	2490	Philco.....	1563
CASTI.....	2305	RCA.....	2325, 2454
Channel Master.....	2365	Sansonic.....	2348
Coby.....	2667	Sunkey.....	2695
Coship.....	2487	Sylvania.....	1563
Daewoo.....	2338	Tivax.....	2185
Daytek.....	2305	Ventura.....	2454
Digital Stream.....	2303	Venturer.....	2454
Dish Network.....	2470	Winegard.....	2454
Echostar.....	2470	Zenith.....	1415
GE.....	2360, 2450	Zentech.....	2491
Goodmind.....	2450	Zinwell.....	2488
Gridlink.....	2348		