

Code Lists / Liste des codes / Lista de Códigos

Audio

Amplifier / Amplificateur / Amplificador

Durabrand	1561
Harman/Kardon	0892
JVC	0331
Left Coast	0892
Lennox	1561
Marantz	0892
Optimus	0823
Philips	0892
Pioneer	0823
Polk Audio	0892
RCA	0823
Sony	0815
Victor	0331
Yamaha	0354

Receiver / Récepteur / Receptor

Accurian	2098
Aiwa	1405, 0189, 0121, 1243, 1641
Akai	1512
Alco	1390
Anam	1609, 1074
Apex Digital	1257, 1430, 1774
Audiotronic	1189
Audiovox	1390
B & K	0701, 0820, 0840
Bose	1229, 0639, 1253, 1629, 1841, 1933
Cambridge Soundworks	1370, 2297
Carver	1189, 0189
Daewoo	1250
Denon	1360, 1142, 2279, 2857
Fisher	1801
Gateway	1517
Go Video	1532
Harman/Kardon	0189, 0891, 1304, 1306, 2241
Hitachi	1801
Insignia	1030, 1077, 1893, 2169, 2175
Integra	0135, 1298, 1320, 1805
JBL	1306
JVC	1374, 1676, 1871, 2239, 2331
Kenwood	1313, 1570, 1569, 0186
KLH	1390, 1412, 1428
Koss	1366
LG	1293, 2197
Linn	0189
Magnavox	1189, 1269, 0189, 0391, 1514
Marantz	1189, 1269, 0189, 1289
Mitsubishi	1393
Onkyo	0135, 0842, 1298, 1320, 1531, 1805
Optimus	1023, 0186, 1074
Oritron	1366
Panasonic	1308, 0367, 1288, 1316, 1548, 1633, 1763, 1764, 2967
Philips	1189, 1269, 0189, 0391, 1266, 1831, 2311
Pioneer	1023, 0244, 0630, 1123, 1384, 1935
Polaroid	1508
Polk Audio	0189, 1289
Proscan	1254
RCA	1023, 1609, 1254, 1074, 1123, 1390, 1511, 2041
Rio	1869

Samsung	1295, 1500, 1868
Sansui	0189
Sanyo	1251, 1469, 1801
Sharp	0186, 1286
Sherwood	1077, 1517, 1653, 1905, 2169
Sherwood Newcastle	2169
Sonic Blue	1532, 1869
Sony	1759, 1058, 1441, 1258, 1622, 1558, 1658, 1758, 1822, 1858, 2172
Stereophonics	1023
Sunfire	1313
Teac	1074, 1390, 1528
Technics	1308
Thorens	1189
Toshiba	1788
Venturer	1390
Vizio	1517
Wards	0189
Yamaha	0176, 0186, 0376, 1176, 1276, 1331, 1375, 1376, 1476, 1815, 2061
Zenith	0857, 1293

Audio Accessories / Accessoires de audio / Acessorios de audio

Accurian	1106
Altec Lansing	0607
Apple	1115, 1644
D-Link	1522
DLO	1155
GPX	2113
Griffin	1891
iDeck	1106
iLive	2113
Monitor Audio	1106
NaviPod	1644
Netgear	1785
Roku	1828
SSI	1522
Yamaha	1809, 1810

Cable / Câble

Amino	1602, 1822
Bright House	1376, 1877
Cable One	1376, 1877
Cablevision	1376, 1877
Charter	1376, 1877, 2187
Cisco	1877, 0877, 1982
Cogeco	0476, 0877, 1187, 1376, 1877
Comcast	1376, 1877, 1982, 2576
Cox	1376, 1877
Digeo	1187, 2187
Director	0476
General Instrument	0476
Homecast	2301
i3 Micro	1602
Insight	1376, 1877
Jerrold	0476
Mediacom	1376, 1877
Motorola	1376, 0476, 1187
Myrio	1602, 1822
Pace	1877
Panasonic	1982
Pioneer	1877, 0877
Rogers	0476, 0877, 1187, 1376, 1877
Scientific Atlanta	1877, 0877
Sejin	1602
Shaw	0476, 0877, 1187, 1376, 1877

Satellite / Satélite

Bell ExpressVu	0775, 1170
Chaparral	0216
Coolsat	1806
Crossdigital	1109
DirecTV	1377, 0392, 0566, 0639, 1639, 1142, 0247, 0749, 1749, 1856, 1076, 1109, 1189, 1414, 1442, 1443, 1609, 1708
Dish Network System	0775, 1505, 1170, 1775
Dishpro	0775, 1505, 1775
Echostar	0775, 1505, 1170, 1775
Expressvu	0775, 1775
GE	0566
General Instrument	0869
GOI	0775, 1775
Hitachi	1250
HTS	0775, 1775
Hughes Network Systems	1142, 0749, 1749, 1442, 1443
Humax	1790
JVC	0775, 1170, 1775
LG	1414
Mitsubishi	0749
Motorola	0869
Next Level	0869
Panasonic	0247, 0701, 1189
Pansat	1807
Philips	1142, 0749, 1749, 1076, 1442
Proscan	0392, 0566
RadioShack	0869
RCA	0566, 0143
Samsung	1377, 1276, 1109, 1442, 1609, 1708
Sony	0639, 1639
Star Choice	0869
Tivo	1142, 1442, 1443

Cable-DVR Combos / Combinés Câble - DVR / Combos de Cable-DVR

Amino	1822
Bright House	1376, 1877
Cable One	1376, 1877
Cablevision	1376, 1877
Charter	1376, 1877, 2187
Cisco	1877, 1982
Comcast	1376, 1877, 1982, 2576
Cox	1376, 1877
Digeo	1187, 2187
Homecast	2301
Insight	1376, 1877
Mediacom	1376, 1877
Motorola	1376, 1187
Myrio	1822
Pace	1877
Panasonic	1982
Pioneer	1877
Scientific Atlanta	1877
Suddenlink	1376, 1877
Time Warner	1376, 1877, 2187
Tivo	2576

Toshiba	0749, 1749, 0790
Ultrasat	1806
Voom	0869
Zenith	1856

Satellite-DVR Combos / Combinés Satellite - DVR / Combos de Satélite-DVR

Bell ExpressVu	0775, 1170
DirecTV	1377, 0392, 0639, 1142, 1076, 1442, 1443
Dish Network System	0775, 1505
Dishpro	0775, 1505
Echostar	0775, 1505, 1170
Expressvu	0775
Hughes Network Systems	1142, 1442, 1443
JVC	1170
Motorola	0869
Philips	1142, 1442
Proscan	0392
Samsung	1442
Sony	0639
Star Choice	0869
Tivo	1142, 1442, 1443

DVD / Lecteurs DVD

Accurian	0675, 1416
Advent	1016
Aiwa	0641
Akai	0695, 0770, 0899, 1089
Alco	0790
Allegro	0869
Amphion Media Works	0872, 1245
AMW	0872, 1245
Apex Digital	0672, 0717, 0755, 0794, 0796, 0797, 0830, 1004, 1056, 1061, 1100, 1480
Arrgo	1023
Aspire Digital	1168, 1407
Astar	1489, 1678
Audiovox	0790, 1121, 1122
B & K	0662
BBK	1224
Bel Canto Design	1571
Blaupunkt	0717
Blue Parade	0571
Bose	2023
Broksonic	0695, 0868, 1419
Buffalo	1882
Centrios	1577
Cinea	0831
CineVision	0876, 0833, 0869
Citizen	0695, 1277
Coby	0778, 0852, 1086, 1107, 1165, 1177, 1351
Craig	0831
Curtis Mathes	1087
CyberHome	0816, 0874, 1023, 1024, 1117, 1129, 1502, 1537
D-Link	1881
D-Vision	1173

Daewoo	0784, 0705, 0833, 0869, 1169, 1172, 1234, 1242, 1441, 1443
Denon	0490, 0634, 2258
Desay	1407
Diamond Vision	1316, 1609, 1610
DigitalMax	1738
Disney	0675, 1270
Dual	1068, 1085
Durabrand	1127, 2164
DVD2000	0521
Emerson	0591, 0675, 0821, 1268
Enterprise	0591
ESA	0821, 1268, 1443
Fisher	0670, 1919
Funai	0675, 1268, 1334
Gateway	1073, 1077, 1158
GE	0522, 0815, 0717
GM	0675, 1268
Go Video	0744, 0715, 0741, 0783, 0833, 0869, 1044, 1075, 1099, 1144, 1158, 1304, 1443, 1730
GoldStar	0741
GPX	0699, 0769
Greenhill	0717
Harman/Kardon	0582, 0702, 1229
Helios	2192
Hello Kitty	0831
Hitachi	0573, 0664, 1247, 1919
Hiteker	0672
Humax	1588
iLo	1348, 1472
Initial	0717, 1472
Insignia	0675, 1268, 2095, 2428
Integra	0627, 1769, 2147
JBL	0702
Jensen	1016
JSI	1423
JVC	0558, 0623, 0867, 1164, 1275, 1550, 1602, 1863
jWin	1049
Kawasaki	0790
Kenwood	0490, 0534, 0682
KLH	0717, 0790, 1149, 1261
Konka	0711, 0719, 0720
Koss	0651, 0896, 1423
Lasonic	0798, 1173
Lennox	1127
LG	0591, 0741, 0869, 1526
LiteOn	1058, 1158, 1416, 1440, 1656, 1738
Loewe	0511
Magnavox	0503, 0539, 0646, 0675, 0821, 1268, 1354, 1472, 1506
Malata	0782
Marantz	0539, 2414
Mclntosh	1273
Memorex	0695, 0831, 1270, 2213
Microsoft	0522, 2083
Mintek	0839, 0717, 1472
Mitsubishi	1521, 0521
NAD	0741
NEC	0785
Nesa	0717
NexTech	1402
Norcent	1003, 0872, 1107, 1265, 1457
Olevia	2331

Onkyo.....	0503, 0627, 1769, 2120, 2147
Oppo.....	0575, 1224, 2185
OptoMedia Electronics.....	0896
Oritron.....	0651
Panasonic.....	0490, 0632, 0703, 1362, 1462, 1490, 1641, 1762
Philco.....	0675
Philips.....	0503, 0539, 2056, 0646, 0675, 0854, 1260, 1267, 1340, 1354, 2084, 2334, 2434
Pioneer.....	0525, 0571, 0142, 0631, 0632, 1460, 1571, 2442
Polaroid.....	1061, 1086, 1245, 1261, 1316, 1478, 1480, 1482, 2313
Polk Audio.....	0539
Portland.....	0770
Presidian.....	0675, 1738
Prima.....	1016
Primare.....	1467
Princeton.....	0674
Proscan.....	0522
ProVision.....	0778
Qwestar.....	0651
RCA.....	0522, 0571, 0717, 0790, 0822, 1022, 1132, 1193, 1769
Rio.....	0869
RJTech.....	1360
Rotel.....	0623
Sampo.....	0698, 0752, 1501
Samsung.....	0490, 0573, 0199, 0899, 1044, 1075, 2329
Sansui.....	0695
Sanyo.....	0670, 0695, 0873, 1919
Schmartz.....	2367
Sensory Science.....	1158
Sharp.....	0630, 0675, 0752, 1256, 2250
Sharper Image.....	1117
Sherwood.....	0633, 0770, 1043, 1077, 1889
Sherwood Newcastle.....	1077
Shinonic.....	0533, 0839
Sigma Designs.....	0674
Sonic Blue.....	0869, 1099
Sony.....	0533, 1533, 0864, 0772, 1033, 1070, 1431, 1432, 1433, 1516, 1548, 1892, 2043
Sova.....	1122
Sungale.....	1074
Superscan.....	0821
SVA.....	0860, 1105
Sylvania.....	0675, 0821, 1268, 2194
Symphonic.....	0675, 0821
Teac.....	0790
Technics.....	0490, 0703
Terapin.....	1031
Theta Digital.....	0571
Tivo.....	1503
Toshiba.....	0503, 0695, 1045, 1154, 1503, 1510, 1588, 1769, 1854, 2277
Tredex.....	0800, 0803
Urban Concepts.....	0503
US Logic.....	0839
Venturer.....	0790
Vizio.....	1064, 1226
Vocopro.....	1360
Xbox.....	0522, 2083
Yamaha.....	0490, 0539, 0545
Zenith.....	0503, 0591, 0741, 0869
Zoec.....	1265

DVD-R	
Accurian.....	0675, 1416
Apex Digital.....	1056
Aspire Digital.....	1168
Astar.....	1489
Broksonic.....	1419
Coby.....	1086
CyberHome.....	1129, 1502
DigitalMax.....	1738
Funai.....	0675, 1334
Gateway.....	1073, 1158
Go Video.....	0741, 1158, 1304, 1730
Humax.....	1588
ilo.....	1348
JVC.....	1164, 1275
LG.....	0741
LiteOn.....	1158, 1416, 1440, 1738
Magnavox.....	0646, 0675, 1506
Panasonic.....	0490
Philips.....	0646, 1340
Pioneer.....	0631, 1460
Polaroid.....	1086
Presidian.....	1738
RCA.....	0522
Samsung.....	0490
Sanyo.....	0670
Sensory Science.....	1158
Sharp.....	0675
Sony.....	1033, 1070, 1431, 1432, 1433
Sylvania.....	0675
Toshiba.....	1510, 1588, 2277
Zenith.....	0741

TV-VCR-DVD Combos / Combinés téléviseur - lecteur DVD / Combos de TV-VCR-DVD	
Controlled by TV / Contrôlé par TV / Controlado por TV	
Akai.....	1903
Broksonic.....	1938
Diamond Vision.....	1996
Emerson.....	1944
ESA.....	1944
Insignia.....	2088
Magnavox.....	1944
Panasonic.....	1946, 1947
Polaroid.....	1992
RCA.....	1953
Sylvania.....	1944
Symphonic.....	1944
Toshiba.....	1945
Controlled by DVD / Contrôlé par DVD / Controlado por DVD	
Akai.....	0899
Broksonic.....	0868
Diamond Vision.....	1609
Emerson.....	0821
ESA.....	0821
Funai.....	1354
Magnavox.....	0821
Panasonic.....	1362, 1462
Polaroid.....	1482
RCA.....	1132
Sharp.....	0630
Superscan.....	0821
Sylvania.....	0821
Symphonic.....	0821
Toshiba.....	1045
Controlled by VCR / Contrôlé par VCR / Controlado por VCR	
Sharp.....	0807

TV/DVD Combos / Combinés téléviseur - lecteur DVD / Combos de TV-DVD	
Controlled by TV / Contrôlé par TV / Controlado por TV	
Accurian.....	1803
Advent.....	1933
Akai.....	1675, 1935, 2232
Apex Digital.....	1943, 1991
Audiovox.....	1937, 1951, 1952
Axion.....	1937
Broksonic.....	1935
Cinego.....	1986
Citizen.....	1935
Diamond Vision.....	1997
Dynex.....	2049, 2184
Emerson.....	1864, 1394, 1963
ESA.....	1963
Funai.....	1963
GFM.....	1963
Hitachi.....	1960
ilo.....	1990
Initial.....	1990
Insignia.....	1963, 2002, 2049
Jensen.....	1933
KLH.....	1962
LG.....	1423, 1993
Magnavox.....	1866, 1963, 1990
Mintek.....	1990
Panasonic.....	1941
Polaroid.....	1523, 1766, 1769, 1962, 1991, 2002
Prima.....	1933
Proscan.....	2256
RCA.....	1948, 1958, 2002, 2187
Samsung.....	1903
Sansui.....	1935
Sharp.....	0818
Sova.....	1952
Sylvania.....	1864, 1394, 1886, 1963
Toshiba.....	1524, 1635, 1935
TruTech.....	2066
Controlled by DVD / Contrôlé par DVD / Controlado por DVD	
Advent.....	1016
Akai.....	0695
Apex Digital.....	0830, 1480
Audiovox.....	1121, 1122
Broksonic.....	0695
Citizen.....	1610
Diamond Vision.....	0675, 1268
Emerson.....	1268
ESA.....	1268
Funai.....	1268
GFM.....	1268
Hitachi.....	1247
ilo.....	1472
Initial.....	1472
Insignia.....	1268
Jensen.....	1016
KLH.....	1261
Konka.....	0719, 0720
LG.....	1526
Magnavox.....	1268, 1472
Mintek.....	1472
Panasonic.....	1490
Philips.....	0854, 1260
Polaroid.....	1261, 1480
Prima.....	1016
RCA.....	1022, 1193
Samsung.....	0839
Sansui.....	0695
Sova.....	1122
Sylvania.....	0675, 1268, 2194
Toshiba.....	0695

VCRs / Magnétoscopes	
ABS.....	1972
Accurian.....	0000
Admiral.....	0209
Adventura.....	0000
Aiwa.....	0000
Alienware.....	1972
Asha.....	0240
Beaumarck.....	0240
Bell & Howell.....	0104
Bell ExpressVu.....	1944
Broksonic.....	0184, 0121, 0209, 0002, 1479, 1815
CCE.....	0072
Citizen.....	1278
Colt.....	0072
Craig.....	0047, 0240, 0072
Curtis Mathes.....	0060, 0162, 1035
Cybernex.....	0240
CyberPower.....	1972
Daewoo.....	1278
Dell.....	1972
Denon.....	0042
DirecTV.....	0739, 0740
Dish Network System.....	1944
Dishpro.....	1944
Durabrand.....	0039, 0038
Dynatech.....	0000
Echostar.....	1944
Emerson.....	0184, 0000, 0121, 0043, 0209, 0002, 0593, 1278, 1479, 1593
Expressvu.....	1944
Fisher.....	0047, 0104
Fuji.....	0033
Funai.....	0000, 0593, 1593
Garrard.....	0000
Gateway.....	1972
GE.....	0060, 0240, 0807, 1035, 1060
GFM.....	1593
Go Video.....	0432, 0614
GOI.....	1944
GoldStar.....	0038, 1237
Gradiente.....	0000
Harley Davidson.....	0000
Harman/Kardon.....	0038
Harwood.....	0072
Hewlett Packard.....	1972
Hi-Q.....	0047
Hitachi.....	0000, 0042, 0089
Howard Computers.....	1972
HP.....	1972
HTS.....	1944
Hughes Network Systems.....	0739, 0042, 0740
Humax.....	0739
Hush.....	1972
iBUYPOWER.....	1972
Kenwood.....	0067, 0038
KLH.....	0072
LG.....	1037
Linksys.....	1972
Lloyd's.....	0000
Logik.....	0072
Magnasonic.....	0593, 1278
Magnavox.....	0039, 0000, 0563, 0593, 1593, 1781
Magnin.....	0240
Matsushita.....	0162, 1162
Media Center PC.....	1972
Memorex.....	0162, 0039, 0047, 0240, 0000, 0104, 0209, 1037, 1162, 1237, 1262
MGA.....	0240, 0043
MGN Technology.....	0240

Microsoft.....	1972
Mind.....	1972
Minolta.....	0042
Mitsubishi.....	0067, 0043, 0807
MTC.....	0240, 0000
Multitech.....	0000, 0072
NEC.....	0104, 0067, 0038
Niveus Media.....	1972
Noblex.....	0240
Northgate.....	1972
Optimus.....	1062, 0162, 0104, 0432, 0593, 1048, 1162, 1262
Orion.....	0184, 0209, 0002, 1479
Panasonic.....	1062, 0162, 0225, 0614, 0616, 1035, 1162, 1262
Penney.....	0240, 0042, 0038, 1035, 1237
Pentax.....	0042
Philips.....	0739, 0618, 1081, 1181
Pioneer.....	0067
Presidian.....	1593
Proffronitron.....	0240
Proscan.....	0060, 1060
Protec.....	0072
Pulsar.....	0039
Quasar.....	0162, 1035, 1162
RadioShack.....	0000, 1037
RCA.....	0060, 0240, 0042, 0807, 0880, 1035, 1060
Realistic.....	0047, 0000, 0104
ReplayTV.....	0614, 0616
Ricavision.....	1972
Runco.....	0039
Samsung.....	0739, 0240, 1014
Sanky.....	0039
Sansui.....	0000, 0067, 0209, 1479
Sanyo.....	0047, 0240, 0104
Scott.....	0184, 0121, 0043
Sears.....	0047, 0000, 0042, 0104, 1237
Sharp.....	0807, 0848
Shintom.....	0072
Shogun.....	0240
Singer.....	0072
Sonic Blue.....	0614, 0616
Sony.....	1232, 0033, 0000, 0636, 1032, 1972
Stack 9.....	1972
STS.....	0042
Sylvania.....	0000, 0043, 0593, 1593, 1781
Symphonic.....	0000, 0593, 1593
Systemax.....	1972
Tagar Systems.....	1972
Teac.....	0000
Technics.....	0162
Teknika.....	0000
Thomas.....	0000
Tivo.....	0739, 0618, 0636, 0740, 1996
TMK.....	0240
Toshiba.....	0043, 0845, 1008, 1145, 1972, 1996
Totevision.....	0240
Touch.....	1972
Unitech.....	0240
Vector Research.....	0038
Videosonic.....	0240
Viewsonic.....	1972
Villain.....	0000
Voodoo.....	1972
Wards.....	0060, 0047, 0240, 0000, 0042, 0072
White Westinghouse.....	0209, 0072
XR-1000.....	0000, 0072
Yamaha.....	0038
Zenith.....	0039, 0033, 0000, 0209, 1139, 1479
ZT Group.....	1972

**TV/VCR Combos / Combinés téléviseur
-magnétoscope / Combos de TV-VCR**

Controlled by TV / Contrôlé par TV / Controlado por TV	
America Action.....	0180
Audiovox.....	0180
Emerson.....	0236
Controlled by VCR / Contrôlé par VCR / Controlado por VCR	
Broksonic.....	0002, 1479
Citizen.....	1278
Colt.....	0072
Curtis Mathes.....	1035
Daewoo.....	1278
Emerson.....	0002, 0593, 1278, 1479
Funai.....	0000
GE.....	0240, 0807, 1035, 1060
GoldStar.....	1237
Harley Davidson.....	0000
Hitachi.....	0000
LG.....	1037
Lloyd's.....	0000
Magnasonic.....	0593, 1278
Magnavox.....	0000, 0593, 1781
Magnin.....	0240
Memorex.....	0162, 1037, 1162, 1237, 1262
MGA.....	0240
Mitsubishi.....	0807
Optimus.....	0162, 0593, 1162, 1262
Orion.....	0002, 1479
Panasonic.....	0162, 1035, 1162, 1262
Penney.....	0240, 1035, 1237
Quasar.....	0162, 1035, 1162
RadioShack.....	0000, 1037
RCA.....	0240, 0807, 1035, 1060
Samsung.....	1014
Sansui.....	0000, 1479
Sanyo.....	0240
Systemax.....	1972
Sears.....	0000, 1237
Sony.....	1232, 0000
Sylvania.....	1781
Symphonic.....	0000, 0593
Thomas.....	0000
Toshiba.....	0845, 1145
Zenith.....	0000, 1479

DTV Converters / Récepteurs TV numériques / Convertidores Digitales

Access HD.....	2185
Airlink 101.....	2491
Alpha Digital.....	2185
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
CASTI.....	2305
Channel Master.....	2365
Coship.....	2487
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Evolution.....	2479
GE.....	2360, 2450
Goodmind.....	2450

DVRS

ABS.....	1972
Alienware.....	1972
Bell ExpressVu.....	1944
CyberPower.....	1972
Dell.....	1972
DirecTV.....	0739, 0740
Dish Network System.....	1944
Dishpro.....	1944
Echostar.....	1944
ExpressVu.....	1944
Gateway.....	1972
Go Video.....	0614
GOI.....	1944
Hewlett Packard.....	1972
Howard Computers.....	1972
HP.....	1972
HTS.....	1944
Hughes Network Systems.....	0739, 0740
Humax.....	0739
Hush.....	1972
iBUYPOWER.....	1972
JVC.....	1944
Linksys.....	1972
Media Center PC.....	1972
Microsoft.....	1972
Mind.....	1972
Niveus Media.....	1972
Northgate.....	1972
Panasonic.....	0614, 0616
Philips.....	0739, 0618
RCA.....	0880
ReplayTV.....	0614, 0616
Samsung.....	0739
Sonic Blue.....	0614, 0616
Sony.....	0636, 1972
Stack 9.....	1972
Sanyo.....	1972
Systemax.....	1972
Tagar Systems.....	1972
Tivo.....	0739, 0618, 0636, 0740
Toshiba.....	1008, 1972, 1996
Touch.....	1972
Viewsonic.....	1972
Voodoo.....	1972
ZT Group.....	1972

Gridlink.....	2348
Insighia.....	1415
Lasonic.....	2348
Magnavox.....	1563
Memorex.....	2486
MicroGEM.....	2489
Philco.....	1563
RCA.....	2325, 2454
Sansonic.....	2348
Sylvania.....	1563
Tivax.....	2185
Ventura.....	2454
Venturer.....	2454
Winegard.....	2454
Zenith.....	1415
Zentech.....	2491
Zinwell.....	2458

Video Accessories / Accessoires de vidéo / Accesorios de vídeo

ABS.....	1272
Access HD.....	2185
ADB.....	2254, 2586
Airlink 101.....	2491
Alienware.....	1272
Alpha Digital.....	2185
Amino.....	1481, 2482
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
AT&T.....	0858
CASTI.....	2305
Channel Master.....	2365
Cisco.....	2345
Coship.....	2487
CyberPower.....	1272
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Entone.....	2302
Epson.....	1563
Evolution.....	2479
Gateway.....	1272
GE.....	2360, 2450
Goodmind.....	2450
Gridlink.....	2348
Hewlett Packard.....	1272
Howard Computers.....	1272
HP.....	1272
Hush.....	1272
iBUYPOWER.....	1272
Insighia.....	1415
KoolConnect.....	1481
Lasonic.....	2348
LG.....	1415
Linksys.....	1272
Magnavox.....	1563
Media Center PC.....	1272
Memorex.....	2486
MicroGEM.....	2489
Microsoft.....	1272
Mind.....	1272
Motorola.....	1998, 0858, 2378
Niveus Media.....	1272
Northgate.....	1272
Philco.....	1563
RCA.....	2325, 2454
Ricavision.....	1272
Roku.....	2371
Sansonic.....	2348
Scientific Atlanta.....	0858, 2345
Sony.....	1272, 1324
Stack 9.....	1272
SureWest.....	1481
Sylvania.....	1563
Systemax.....	1272
Tagar Systems.....	1272
Tivax.....	2185
Toshiba.....	1272
Touch.....	1272

TVs / Téléviseurs

Accurian.....	1803
Action.....	0873
Admiral.....	0093, 0463
Advent.....	0761, 0783, 0815, 0817, 0842, 1933
Aiko.....	0092
Akai.....	0812, 1675, 0702, 0030, 0672, 1207, 1676, 1903, 1935, 2078, 2232
Albatron.....	0700, 0843
America Action.....	0180
Ampro.....	0751
Anam.....	0180
AOC.....	0030, 1365, 1590, 2014
Aomni.....	1623
Apex Digital.....	0748, 0879, 0765, 0767, 0890, 1217, 1943, 1991
Astar.....	1548
Audiovox.....	0451, 0180, 0092, 0623, 0710, 0802, 0846, 0875, 1284, 1937, 1951, 1952
Aventura.....	0171
Axion.....	1937
Bell & Howell.....	0154
BenQ.....	1032, 1315
Bradford.....	0180
Broksonic.....	0236, 0463, 1935, 1938
Bydsign.....	1309, 1311
Cadia.....	1283
Candle.....	0030
Carnivale.....	0030
Carver.....	0054
Celebrity.....	0000
Celera.....	0765
Changhong.....	0765
Cinego.....	1986
Citzen.....	0060, 0030, 0092, 1935
Clarion.....	0180
Coby.....	2017
Commercial Solutions.....	1447, 0047
Contec.....	0180
Craig.....	0180
Crosley.....	0054
Crown.....	0180
Curtis Mathes.....	0047, 0054, 0154, 0451, 0093, 0060, 0702, 0030, 0145, 0166, 0466, 1147, 1347
CXC.....	0180
CyberHome.....	0794
Cytron.....	1326

Ventura.....	2454
Venturer.....	2454
Verizon.....	2378
Viewsonic.....	1272
Voodoo.....	1272
Vudu.....	2298
Winegard.....	2454
Zenith.....	1415
Zentech.....	2491
Zinwell.....	2488
ZT Group.....	1272

Daewoo.....	0451, 0092, 1661, 0623, 0661, 0672
Dell.....	1264, 1080, 1178, 1403, 1863
Denon.....	0145
Diamond Vision.....	1996, 1997
Digital Lifestyles.....	1765
Dumont.....	0017
Durabrand.....	0463, 0180, 0178, 0171, 1034
Dwin.....	0720
Dynex.....	1463, 2049, 2184
Electroband.....	0000
Electrograph.....	1755, 1623
Electrohome.....	0463
Element.....	1687
Emerson.....	1864, 0154, 0236, 0463, 0180, 0178, 0171, 0623, 1394, 1665, 1944, 1963
Emprex.....	1422, 1546, 1765
Envision.....	0030, 0813, 1365, 2014
Epson.....	0833, 0840, 1290
ESA.....	0812, 0171, 1944, 1963
Fisher.....	0154
FlexVision.....	0710
Fujitsu.....	0809, 0683, 0853, 2008
Funai.....	0180, 0171, 1271, 1963
Futuretech.....	0180
Gateway.....	1755, 1001, 1002, 1003, 1756
GE.....	1447, 0047, 0051, 0451, 0178, 1347
GFM.....	0171, 1665, 1963, 2167
Gibraltar.....	0017, 0030
Go Video.....	0886
GoldStar.....	0178, 0030
Grundy.....	0180
Haier.....	1034, 1748, 1749
Hallmark.....	0178
Hannspre.....	1348, 1351, 1352
Harman/Kardon.....	0054
Harsper.....	1206
Harvard.....	0180
Havermy.....	0093
Helios.....	0865
Hello Kitty.....	0451
Hewlett Packard.....	1494, 1088, 1089, 1101, 1502
Hisense.....	0748
Hitachi.....	1643, 1145, 0145, 0797, 1960
HP.....	1494, 1088, 1089, 1101, 1502
Hyundai.....	0849, 1219, 1294
iLO.....	1286, 1603, 1665, 1684, 1990
Infinity.....	0054
Initial.....	1603, 1990
Insighia.....	1564, 0171, 1204, 1326, 1517, 1963, 2002, 2049, 2088
Inteq.....	0017
iRIS.....	2189
JBL.....	0054
JCB.....	0000
Jensen.....	0761, 0815, 0817, 1299, 1933
JVC.....	0053, 0731, 1253, 1601, 1774
KDS.....	1498, 1687
KEC.....	0180
Kenwood.....	0030
KLH.....	0765, 0767, 1962
Kost.....	1262, 1483
KTV.....	0180, 0030
LG.....	1423, 0178, 0700, 0856, 1178, 1325, 1768, 1993

LXI0047, 0054, 0154, 0156, 0178
MAG1498, 1687
Magnavox1454, 1866, 0054, 0030, 0706, 0802, 1198, 1254,
1365, 1525, 1944, 1963, 1990
Marantz0054, 0030, 0704, 0854, 0855, 1154, 1398
Matsushita0250, 0650
Maxent1755, 0762, 1211, 1757
Megapower0700
Megatron0178, 0145
Memorex0154, 0463, 0150, 0178
MGA0150, 0178, 0030
Midland0047, 0017, 0051
Mintek1603, 1990
Mitsubishi1250, 0093, 0150, 0178, 0836, 0868, 1550
Monivision0700, 0843
Motorola0093, 0835
Moxell0835
MTC0060, 0030
Multitech0180
NAD0156, 0178, 0866, 1156
NEC0030, 0497, 0882, 1398, 1704
NetTV1755, 0762
Nexus Electronics2183
Nikko0178, 0030, 0092
Norcent0748, 0824, 1089, 1365, 1589, 1590, 1591
Norwood Micro1286, 1296, 1303
NTC0092
NuVision1657, 2158
Olevia1610, 1144, 1240, 1331
Olympus1342
Onwa0180
Optimus0250, 0154, 0166, 0650
Optoma0887
Optonica0093
Orion0236, 0463, 1463
Panasonic0250, 1480, 0051, 0650, 1291, 1941, 1946, 1947
PARK2194, 2202
Penney0047, 0156, 0051, 0060, 0178, 0030, 1347
Petters1523
Philco0054, 0030
Philips1454, 0054, 0690, 1154, 1483, 1744, 1867
Pilot0030
Pioneer1457, 0166, 0679, 0866, 1260, 1398
Planar1496
Polaroid1523, 0765, 2121, 2120, 2119, 2002, 1992, 1991, 1962, 1769, 1767, 1766,
1687, 1498, 1341, 1328, 1327, 1326, 1316, 1314, 1286, 1276, 1262, 0865
Portland0092
Prima0761, 0783, 0815, 0817, 1933
Princeton0700
Prism0051
Proscan1447, 0047, 1347, 2147, 2256
Proton0178, 0466
Protron1320, 1323
Proview0835, 1498, 1687
Pulsar0017
Puneet1546
Quasar0250, 0051, 0650
RadioShack0047, 0154, 0180, 0178, 0030
RCA1547, 1447, 0047, 0090, 0679, 1047, 1147, 1247, 1347, 1781, 1948,
1953, 1958, 2002, 2187, 2247
Realistic0154, 0180, 0178, 0030
RevolutionHD1623

Runco0017, 0030, 0497, 0603, 1398, 1629
Sampo1755, 0030, 0762
Samsung0812, 0060, 0702, 0178, 0030, 0766, 0814, 1060, 1575, 1903
Sansui0463, 1409, 1935
Sanyo0154, 0088, 0799, 0893, 1142
Sceptre0878, 1217, 1360, 1599
Scotch0178
Scott0236, 0180, 0178, 1711
Sears0047, 0054, 0154, 0156, 0178, 0171
Sharp0818, 0093, 0491, 0688, 0689, 0851, 1602
Sheng Chia0093
Sherwood1399
Signet1262
SIM2 Multimedia1297
Sole1483, 1623
Sony0000, 0810, 0834, 1317, 1685
Soundesign0180, 0178
Sova1320, 1952
Soyo1546, 1826
Spectroniq1498, 1687
Squareview0171
SSS0180
Starlite0180
Studio Experience0843
Superscan0093, 0864
Supreme0000
SVA0748, 0865, 0870, 0872
Sylvania1864, 0054, 0030, 0171, 1271, 1314, 1394, 1665, 1886, 1944, 1963
Symphonic0180, 0171, 1944
Syntax1610, 1144, 1240, 1331
Tandy0093
Tatung1101, 1285, 1286, 1287, 1288, 1361, 1756
Technics0250, 0051
Techview0847
Techwood0051
Teknika0054, 0180, 0150, 0060, 0092
Telefunken0702
TMK0178
TNCI0017
Toshiba1524, 0154, 0156, 1256, 0060, 1945, 1935, 1704, 1656, 1635, 1356, 1343,
1325, 1306, 1156, 0845, 0832, 0650
TruTech1723, 2066
TVS0463
Ultra1323
US Logic1286, 1303
Vector Research0030
Victor0053
Vidikron0054, 1398, 1629
Vidtech0178
Viewsonic1755, 0797, 0857, 0864, 0885, 1330, 1342,
1578, 1627, 1742, 2014, 2087
Viore1207, 1684
Visart1336
Vizio1758, 0864, 0885, 1499, 1756
Wards0054, 0178, 0030, 0866, 1156
Waycon0156
Westinghouse1712, 0885, 0889, 0890, 1282, 1577
White Westinghouse0463, 0623
Wyse1365
Yamaha0030, 0769, 0797, 0833, 0839
Zenith0017, 0463, 0178, 0092

DLP

Hewlett Packard1494
HP1494
Magnavox1525
Mitsubishi1250
Optoma0887
Panasonic1291
RCA1447
Samsung0812, 1060
SIM2 Multimedia1297
SVA0872
Toshiba1524, 1306
Vizio1499

HDTV

Advent0842
Hitachi1960
Marantz0854
Mitsubishi0150
Olevia1610
Panasonic0250, 0650, 1291
Pioneer0679
RCA1447
Samsung0812, 0702
Sharp0688, 0689
Toshiba1256

LCD / ACL

Accurian1803
Action0873
Akai1675, 1676, 1935, 2232
AOC1365, 2014
Aomni1623
Apex Digital0890, 1217
Astar1548
Audiovox0180, 0710, 0802, 0846, 0875, 1284, 1937, 1951, 1952
BenQ1315
Byd:sign1309, 1311
Cadia1283
Citizen1935
Coby2017
CyberHome0794
Dell1264, 1080, 1178, 1863
Digital Lifestyles1765
Dynex2049, 2184
Element1687
Emerson1864, 1394, 1963
Emprex1422, 1546, 1765
Envision0813, 1365, 2014
FlexVision0710
Funai0171
GFM2167
Go Video0886
Haier1748, 1749
Hannspree1348, 1351
Harsper1206
Hewlett Packard1088
Hitachi1643
HP1088
Hyundai0849, 1219, 1294
iLo1286, 1603, 1684, 1990
Initial1603, 1990

Insignia1564, 1204, 1517, 2002, 2049
iRIS2189
Jensen1299
JVC1601, 1774
Kost1262
LG1423, 0856, 1178, 1768, 1993
Magnavox1866, 0802, 1198, 1365, 1990
Marantz0855
Maxent1755, 0762, 1211, 1757
Mintek1603, 1990
Mitsubishi1250
NetTV0762
Nexus Electronics2183
Norcent1365, 1589, 1591
Norwood Micro1286, 1296
NuVision1657, 2158
Olevia1610, 1144, 1240, 1331
Panasonic1480, 0650, 1941
PARK2194, 2202
Petters1523
Philips1454, 1483, 1744, 1867
Pioneer1260
Planar1496
Polaroid1523, 1262, 1276, 1316, 1341, 1498, 1687, 1766, 1767,
1769, 2119, 2120, 2120, 2121
Proscan2147, 2256
Protron1320, 1323
Puneet1546
RCA0047, 1781, 1958, 2187, 2247
RevolutionHD1623
Runco1629
Sampo1755, 0762
Samsung0812, 0766, 0814, 1575
Sansui1409
Sanyo1142
Sceptre0878, 1217, 1360, 1599
Scott1711
Sharp0818, 0093, 1602
Sherwood1399
Signet1262
Sole1483, 1623
Sony0810, 1685
Sova1320
Soyo1546, 1826
Superscan0864
SVA0870
Sylvania1864, 0171, 1271, 1314, 1394, 1886
Symphonic0171
Syntax1610, 1144, 1240, 1331
Tatung1286
Techview0847
Toshiba1524, 0845, 1343, 1635, 1656
TruTech1723
Ultra1323
US Logic1286
Vidikron1398, 1629
Viewsonic0857, 0864, 0885, 1330, 1578, 1627, 1742, 2014, 2087
Viore1684
Visart1336
Vizio1758, 0864, 0885, 1756
Westinghouse1712, 0885, 0889, 0890, 1282, 1577

Plasma

Akai0812, 1675, 1207, 2078
Albatron0843
AOC1590
Aomni1623
BenQ1032
Byd:sign1311
Daewoo0661
Dell1264, 1863
Electrograph1755, 1623
ESA0812
Fujitsu0809, 0683, 0853, 2008
Funai1271
Gateway1755, 1001, 1002, 1003, 1756
Haier1748
Harsper1206
Helios0865
Hewlett Packard1089, 1502
Hitachi1643, 0797
HP1089, 1502
iLo1684
Insignia1564
JVC0731
LG1423, 0178, 0856
Magnavox1866
Marantz0704, 1398
Maxent1755, 1757
Mitsubishi0836
Monivision0843
Motorola0835
Moxell0835
NEC1398, 1704
NetTV1755
Nexus Electronics2183
Norcent0824, 1089, 1590
Norwood Micro1303
Panasonic0250, 1480, 0650
Philips0690, 1744
Pioneer1457, 0679, 1260, 1398
Polaroid0865, 1276, 1327, 1328
Proview0835
Puneet1546
RevolutionHD1623
Runco1398
Sampo1755
Samsung0812
Sanyo1142
Sole1623
Sony0000, 0810, 1317
Studio Experience0843
SVA0865
Sylvania1271, 1394
Tatung1101, 1285, 1287, 1288, 1756
Toshiba0650, 1704
US Logic1303
Viewsonic1755, 0797
Viore1207, 1684
Vizio1758, 1756
Yamaha0797
Zenith0178