

# Code List

## TV Codes

Abex	.....	172
Admiral	.....001, 046, 047, 083, 095, 173, 191,	211
Adventura	.....	174
Aiko	.....	016
Akai	.....	002
Alleron	.....	046, 047
Amtron	.....	038
Anam National	.....003, 038, 192, 193, 194	
AOC	.....004, 005, 006, 007, 082, 195, 196	
Apex	.....	236, 240, 241
Audiovox	.....	038
Belcor	.....	004
Bell & Howell	.....001, 048, 049, 073, 083, 162	
Bradford	.....	038
Broksonic	.....	000, 004, 250, 280
Brokwood	.....	004
Candle	.....004, 006, 008, 132, 174, 196	
Celebrity	.....	002
Citizen	.....004, 006, 008, 016, 038, 105, 132, 171, 196	
Colortyme	.....004, 006, 010, 196, 200	
Concerto	.....	004, 006, 196
Contec/Cory	.....	012, 013, 038, 063
Craig	.....	038
Crosley	.....	000, 062
Crown	.....038, 062, 130, 171	
Curtis Mathes	.....000, 004, 006, 015, 048, 049, 073, 105,	
	.....	162, 171, 196, 212
CXC	.....	038
Daewoo	.....004, 005, 006, 016, 017, 082, 127, 171, 190, 196, 202	
Daytron	.....	004, 006, 171, 196
Dimensia	.....	000, 212
Dumont	.....	004, 151, 196, 217
Dynatech	.....	004
Electroband	.....	002
Electrohome	.....000, 002, 003, 004, 006, 019, 020, 022, 064, 196	
Emerson	.....004, 006, 012, 023, 024, 025, 026, 027, 028, 029	
	.....030, 031, 032, 033, 034, 035, 036, 037, 038, 039, 041, 042,	
	.....043, 044, 046, 047, 048, 049, 073, 123, 124, 162, 171, 177	
	.....	179, 191, 196, 208
Envision	.....	004, 006, 196
Fisher	.....	048, 049, 051, 073, 162, 180
Fujitsu	.....	046, 047
Funai	.....	038, 046, 047, 189
Futuretec	.....	038
GE	.....000, 003, 004, 006, 022, 052, 054, 055, 064, 087, 100,	
	.....	164, 165, 166, 167, 168, 181, 196, 203, 212, 213, 233
Gilbralter	.....	004, 151
Goldstar	.....004, 005, 006, 012, 019, 056, 057, 058, 082, 155	
	.....	156, 171, 172, 196
Grundy	.....	038, 046, 047, 171
Hallmark	.....	004, 006, 196
Harvard	.....	038
Hisense	.....	237
Hitachi	.....004, 006, 012, 013, 059, 060, 061, 063, 135, 136,	
	.....	137, 158, 159, 140, 141, 142, 143, 144, 145, 146,
	.....	148, 150, 179, 185, 196, 198, 199
IMA	.....	038
Infinity	.....	062, 130
Janeil	.....	174
JBL	.....	062, 130
JCB	.....	002
JC Penney	.....000, 004, 005, 006, 008, 013, 022, 052, 054,	
	.....055, 057, 058, 063, 064, 072, 082, 087, 100, 104,	
	.....	105, 109, 132, 166, 167, 171, 172, 181, 196, 201,
	.....	203, 207, 212, 233
Jensen	.....	004, 006, 196
JVC	.....012, 013, 054, 055, 060, 063, 065, 066	
	.....	067, 123, 157, 158, 159, 182, 239
Kawasho	.....	002, 004, 006, 196
Kenwood	.....	004, 006, 019, 196
KLH	.....	236, 240, 241
Kloss Novabeam	.....	038, 068, 069, 174, 183
KTV	.....	038, 070, 171, 177
LG	.....	005, 082
Loewe	.....	062, 130
Logik	.....	001, 083
Luxman	.....	004, 006, 196
LXI	.....000, 006, 048, 049, 062, 071, 072, 073, 100,	
	.....	109, 130, 162, 181, 196, 203, 207, 212, 233
Magnavox	.....000, 004, 006, 008, 019, 062, 068, 069, 075, 076,	
	.....	077, 088, 130, 131, 132, 133, 134, 183, 196, 219, 235
Majestic	.....	001, 083
Marantz	.....004, 006, 059, 062, 078, 130, 196, 199	
Megatron	.....	006, 059, 196, 199
Memorex	.....001, 005, 006, 046, 047, 048, 049, 073, 082, 083,	
	.....	162, 191, 196
MGA	.....004, 005, 006, 019, 022, 051, 064, 079, 080, 082, 196	
Midland	.....	054, 055, 151, 171, 172, 181
Minutz	.....	052
Mitsubishi	.....004, 005, 006, 019, 022, 051, 064, 079, 080,	
	.....	081, 082, 125, 135, 196
Montgomery Ward	.....	001, 083
Motorola	.....	003, 173

MTC	.....004, 005, 006, 082, 105, 196
Multitech	.....038
Multivision	.....084
NAD	.....006, 071, 072, 109, 136, 185, 196, 207
NEC	.....003, 004, 005, 006, 010, 082, 196, 200
Nikko	.....006, 016, 196
NTC	.....016
Onwa	.....038
Optimus	.....136, 185
Optonica	.....095, 173
Orion	.....030, 035, 191, 208
Panasonic	.....003, 054, 055, 062, 109, 130, 170, 214, 350, 351
Philco	.....003, 004, 005, 006, 008, 012, 019, 062, 068, 069, 075, 077, 082, 088, 130, 132, 134, 183, 196
Philips	.....002, 003, 004, 008, 012, 019, 062, 068, 069, 075, 076, 086, 087, 088, 130, 132, 134, 167, 183, 196
Pilot	.....004, 171, 196
Pioneer	.....004, 006, 090, 091, 092, 136, 179, 185, 196
Portland	.....004, 005, 006, 016, 082, 171, 196
Price Club	.....105
Prima	.....238
Prism	.....054, 055
PROSCAN	.....000, 100, 181, 203, 212, 233
Proton	.....004, 006, 012, 093, 196
Pulsar	.....004, 151
Quasar	.....003, 054, 055, 070, 109, 170, 214
Radio Shack	.....000, 048, 049, 073, 162, 212
Radio Shack/Realistic	.....004, 006, 012, 038, 048, 049, 073, 095, 162, 171, 172, 196
RCA	.....000, 003, 004, 005, 006, 007, 019, 054, 055, 082, 096, 098, 099, 100, 101, 102, 103, 129, 179, 181, 188, 190, 196, 202, 203, 212, 215, 233, 281, 352
Runco	.....151, 217
Sampo	.....004, 006, 171, 172, 196, 242
Samsung	.....004, 005, 006, 012, 013, 015, 017, 019, 082, 104, 105, 106, 171, 172, 196, 201, 204
Sansui	.....191, 208, 282
Sanyo	.....004, 048, 049, 073, 080, 107, 162, 169, 180, 196
Scotch	.....006, 196
Scott	.....004, 006, 012, 024, 035, 038, 046, 047, 196
Sears	.....000, 004, 006, 013, 019, 046, 047, 048, 049, 051, 063, 066, 071, 072, 073, 100, 109, 110, 162, 180, 181, 189, 196, 203, 207, 212, 233
Sharp	.....004, 006, 012, 026, 029, 095, 111, 112, 113, 122, 171, 173, 196
Shogun	.....004, 196
Signature	.....001, 083, 173
Simpson	.....008
Sony	.....002, 205, 216, 218
Soundesign	.....004, 006, 008, 038, 046, 047, 132, 196
Squareview	.....189
SSS	.....004, 038
Starlite	.....038
Supre-Macy	.....174
Supreme	.....002
Sylvania	.....004, 006, 008, 019, 062, 068, 069, 075, 076, 077, 088, 116, 130, 132, 134, 161, 183, 196, 353
Symphonic	.....026, 029, 033, 038, 046, 047, 155, 189
Tandy	.....173
Tashiko	.....072
Tatung	.....003
Technics	.....054, 055
Techwood	.....004, 006, 054, 055, 196
Teknika	.....001, 004, 005, 006, 008, 012, 013, 016, 038, 046, 047, 063, 076, 082, 083, 105, 132, 170, 171, 196, 214
Telecaption	.....117
Tera	.....004, 012, 093
TMK	.....004, 006, 196
Toshiba	.....000, 048, 049, 071, 072, 073, 105, 109, 117, 118, 160, 161, 162, 190, 201, 207, 283
Totevision	.....171
Universal	.....052, 087, 166, 167
Victor	.....066, 182
Vidtech	.....004, 005, 006, 196
Viking	.....174
Wards	.....000, 001, 004, 005, 006, 019, 024, 033, 046, 047, 052, 062, 068, 069, 075, 076, 082, 083, 087, 088, 095, 119, 120, 130, 134, 166, 167, 173, 183, 196, 212
White Westinghouse	.....000, 001, 190, 191
Yamaha	.....004, 005, 006, 019, 082, 196
Zenith	.....000, 001, 004, 051, 083, 151, 152, 153, 154, 196, 210, 217

## VCR Codes

Admiral	.....001
Adventura	.....026
Aiko	.....027
Aiwa	.....026
Akai	.....003, 005, 007, 008, 111, 112, 113, 119
Allegro	.....145
American High	.....021
Asha	.....013
Audio Dynamics	.....009, 010
Audiovox	.....014, 054
Beaumarck	.....013

Bell & Howell	.....011
Broksonic	.....012, 025, 031, 135, 235
Calix	.....014, 054
Candle	.....013, 014, 015, 016, 017, 018, 019
Canon	.....021, 022
Capehart	.....020, 110
Carver	.....062
CCE	.....027, 061
Citizen	.....013, 014, 015, 016, 017, 018, 019, 027, 054
Colortyme	.....009
Colt	.....061
Craig	.....013, 014, 023, 054, 061
Curtis Mathes	.....000, 009, 013, 016, 018, 021, 022, 024 .....086, 087, 089, 091, 115
Cybernex	.....013
Daewoo	.....015, 017, 019, 025, 026, 027, 028, 110
Daytron	.....061, 110
DBX	.....009, 010
Dimensia	.....000, 086, 089
Dynatech	.....026
Electrohome	.....014, 029, 054
Electrohome	.....014
Emerson	.....003, 007, 012, 014, 015, 021, 024, 025, 026, 029, .....030, 031, 032, 033, 034, 036, 037, 038, 039, 040, 041, 042, .....044, 045, 046, 047, 054, 065, 105, 113, 116, 117, 130, 136
Fisher	.....011, 023, 048, 049, 050, 051, 052, 118
Fuji	.....021, 119
Funai	.....026
Garrard	.....026
GE	.....000, 013, 021, 022, 053, 086, 087, 089, 091, 115, 120
Go Video	.....134, 137
Goldstar	.....009, 014, 018, 054, 057
Gradiente	.....026
Harley Davidson	.....026
Harman Kardon	.....009
Harwood	.....061
Headquarter	.....011
Hi-Q	.....023
Hitachi	.....026, 055, 056, 057, 084, 107, 111, 120
Instant Replay	.....021
JCL	.....021
JC Penney	.....009, 010, 011, 012, 013, 014, 021, 022, 051 .....054, 055, 056, 060, 061, 062, 084, 107, 118
Jensen	.....055, 056, 084, 111
JVC	.....009, 010, 011, 018, 111, 123, 138
Kenwood	.....009, 010, 011, 016, 018, 111, 123
KLH	.....061
Kodak	.....014, 021, 054
LG	.....014, 054
Lloyd's	.....026
Logik	.....061
LXI	.....014, 054
Magnavox	.....021, 022, 062, 063, 104, 105, 108, 124
Magnin	.....013
Marantz	.....009, 010, 011, 016, 018, 021, 022, 062, 064, 076
Marta	.....014
Matsushita	.....021
MEI	.....021
Memorex	.....001, 011, 013, 014, 021, 022, 023, 026, 031 .....054, 104, 130
MGA	.....029, 065, 113
MGN Technology	.....013
Midland	.....053
Minolta	.....055, 056, 084, 107
Mitsubishi	.....029, 055, 056, 065, 066, 067, 068, 069, 070 .....071, 072, 073, 074, 084, 106, 113, 123
Montgomery Ward	.....001, 075
Motorola	.....001, 021
MITC	.....013, 126
Multitech	.....013, 016, 026, 053, 061
NEC	.....009, 010, 011, 016, 018, 064, 076, 078, 079, 111, 123
Nikko	.....014, 054
Noblex	.....013
Olympus	.....021
Optimus	.....001, 014, 054
Optonica	.....096
Orion	.....000, 031, 086, 089, 130
Panasonic	.....021, 022, 109, 125, 126, 127, 265, 266
Pentax	.....016, 055, 056, 084, 107, 120,
Pentax Research	.....018
Philco	.....021, 022, 062, 063
Philips	.....021, 022, 062, 096, 124, 139
Pilot	.....014
Pioneer	.....010, 055, 080, 081, 123
Portland	.....016, 017, 019, 110
PROSCAN	.....000, 083, 086, 089
Protec	.....061
Pulsar	.....104
Quarter	.....011
Quartz	.....011
Quasar	.....021, 022, 125
Radio Shack	.....001, 014, 050, 054, 096
Radio Shack/Realistic	.....011, 013, 014, 021, 022, 023, 026 .....029, 049, 050, 054, 096
Radix	.....014, 054
Randex	.....014
RCA	.....000, 003, 007, 013, 021, 022, 055, 056, 082, 083, 084 .....085, 086, 087, 088, 089, 090, 091, 100, 107, 115, 120 .....125, 140, 267
Realistic	.....001, 011, 013, 014, 015, 021, 022, 023, 026, 029, .....049, 054, 096
Ricoh	.....128
Runco	.....104

## VCR Codes (continued)

Samsung	.....005, 013, 015, 033, 053, 112, 141, 142
Sanky	.....001, 104
Sansui	.....010, 031, 092, 111, 123, 130
Sanyo	.....011, 013, 023, 143
Scott	.....012, 015, 025, 032, 058, 065, 116
Sears	.....000, 011, 014, 021, 023, 026, 028, 048, 049, 050, 051
	.....054, 055, 056, 084, 086, 089, 107, 118
Sharp	.....001, 017, 029, 094, 095, 096, 097
Shintom	.....056, 061, 084, 098, 119
Shogun	.....013
Signature	.....001
Singer	.....021, 061, 128
Sony	.....098, 099, 119, 144
STS	.....021, 107
Sylvania	.....021, 022, 026, 062, 063, 065, 124, 268
Symphonic	.....026
Tandy	.....011
Tashiko	.....014, 054
Tatung	.....111
Teac	.....026, 085, 111
Technics	.....021, 109
Teknika	.....014, 021, 022, 026, 054, 100, 129
TMK	.....013, 024, 047
Toshiba	.....015, 049, 051, 055, 065, 113, 116, 118
Totevision	.....013, 014, 054
Unitech	.....013
Vector Research	.....009, 010, 015, 016
Victor	.....010
Video Concepts	.....009, 010, 015, 016, 113
Videosonic	.....013
Wards	.....001, 013, 014, 015, 021, 022, 023, 026, 029, 054,
	.....055, 056, 061, 084, 088, 090, 096, 101, 102, 103
	.....107, 116
XR-1000	.....021, 026, 061
Yamaha	.....009, 010, 011, 018, 111
Zenith	.....026, 098, 104, 119, 128, 130, 145

## PVR/DVR Codes

RePlay	.....316
TiVo	.....315

## DVD Player Codes

Aiwa	.....350
Allegro	.....510
Apex	.....372, 373, 374
Broksonic	.....500, 600
Daewoo	.....375
Emerson	.....376, 377, 501
Funai	.....377
GE	.....160, 370, 378
Go Video	.....502
Hitachi	.....351, 379
JBL	.....251
JVC	.....161, 252, 352, 386, 503
Kenwood	.....380
Konka	.....353, 354
Koss	.....253, 254, 381
Lasonic	.....382
Magnavox	.....162, 357, 358, 383
Memorex	.....384
Mintek	.....385
Mitsubishi	.....163
NAD	.....376
Onkyo	.....255, 387
Oritron	.....392
Panasonic	.....256, 257, 300, 301, 355, 388
Philips	.....162, 258, 356, 357, 358, 389, 504
Pioneer	.....165, 259, 390, 391
PROSCAN	.....160, 370
Qwestar	.....392
RCA	.....160, 260, 302, 370, 371, 393, 409, 505, 601
Samsung	.....394, 395, 396, 506, 507
Sansui	.....397, 602
Sanyo	.....359, 508
Sharp	.....398, 399, 400, 401
Sony	.....166, 261, 360, 361, 402, 403, 404, 509
Sylvania	.....303, 377
Toshiba	.....162, 167, 362, 363, 405, 406, 407, 603
Venturer	.....262
Xbox ®*	.....160
Yamaha	.....258
Zenith	.....364, 408, 510

\*Requires use of Xbox ® DVD playback kit.

## Portable DVD Player Codes

RCA.....	371
Sharp.....	399

## CD Player Codes

ADC.....	200, 201, 220
ADO.....	201
Aiwa.....	175, 203
Akai.....	205
Denon.....	208
Dynatech.....	177
Emerson.....	178
Fisher.....	179, 212, 213
GE.....	216
Hitachi.....	180
Inkel.....	220
JVC.....	181, 221
Kenwood.....	183, 222, 224
Luxman.....	225
Marantz.....	185, 226
MCS.....	228
Mitsubishi.....	229, 230
Nakamichi.....	232, 233
NEC.....	184
Onkyo.....	186, 234, 235
Optimus.....	237, 238, 239
Panasonic.....	188
Pioneer.....	189, 240
RCA.....	190, 211
Sanyo.....	250
Sears.....	207
Sherwood.....	243
Sony.....	195, 209, 244
Teac.....	245, 246, 247
Technics.....	197
Toshiba.....	231
Yamaha.....	198, 199, 248

## TV/VCR Combo Codes

	TV	VCR
Broksonic.....	250	235

## TV/DVD Combo Codes

	TV	DVD
Broksonic.....	280	600
RCA.....	281	601
Sansui.....	282	602
Toshiba.....	283	603

## TV/VCR/DVD Combo Codes

	TV	VCR	DVD
Panasonic.....	350	265	300
.....	351	266	301
RCA.....	352	267	302
Sylvania.....	353	268	303

## VCR/DVD Combo Codes

	VCR	DVD
Broksonic.....	135	500
Emerson.....	136	501
Go Video.....	137	502
JVC.....	138	503
Philips.....	139	504
RCA.....	140	505
Samsung.....	141	506
.....	142	507
Sanyo.....	143	508
Sony.....	144	509
Zenith.....	145	510

## Home Theater (HTIB) Systems Codes

	DVD	Audio
JBL.....	251	300
JVC.....	252	301
Koss.....	253	302
.....	254	303
Onkyo.....	255	304
Panasonic.....	256	305
.....	257	306
Philips.....	258	307
Pioneer.....	259	308
RCA.....	260	309
Sony.....	261	310
Venturer.....	262	311

## Satellite Codes

Alphastar.....	.079
Bell ExpressVu.....	.078, 091
Chaparral.....	.056, 057
Dish Network.....	.078, 089, 091
Drake.....	.058, 059
EchoStar.....	.089
GE.....	.047, 071, 080, 081, 093
General Instruments.....	.060, 061, 062
Hitachi.....	.083, 084
Hughes Network Systems.....	.077, 083, 090
JVC.....	.082
Magnavox.....	.085
Motorola.....	.047, 071, 080, 081
Panasonic.....	.075
Philips.....	.085
Primestar.....	.076
PROSCAN.....	.047, 071, 080, 081, 093
RCA.....	.047, 071, 080, 081, 093
Realistic.....	.063
Sony.....	.072
Star Choice.....	.076, 092
STS1.....	.064
STS2.....	.065
STS3.....	.066
STS4.....	.067
Toshiba.....	.068, 073
Uniden.....	.086

## HDTV Tuner Codes

RCA.....	.200
----------	------

## Cable Box Codes

ABC.....	.001, 003, 004, 005, 006, 007
Antronix.....	.008, 009
Archer.....	.008, 009, 010, 011
Cabletenna.....	.008
Cableview.....	.008
Century.....	.011
Citizen.....	.011
Colour Voice.....	.012, 013
Comtronics.....	.015
Contec.....	.016
Eastern.....	.017
Garrard.....	.011
GC Electronics.....	.009
GE.....	.000, 003
Gemini.....	.018, 019
General Instruments.....	.000, 001, 003, 046, 049
Hamlin.....	.020, 021, 022, 028, 035
Hitachi.....	.003
Jasco.....	.011
Jerrold.....	.000, 001, 003, 005, 007, 018, 023, 024, 046, 049
Magnavox.....	.025
Motorola.....	.000, 003, 046
Movie Time.....	.027, 028
NEC.....	.005
NSC.....	.027, 028
Oak.....	.016, 029
Panasonic.....	.000, 048
Philips.....	.011, 012, 013, 015, 019, 025, 030, 031, 032
Pioneer.....	.033, 034
PROSCAN.....	.003
RCA.....	.000, 007, 049
Realistic.....	.009

Regal .....	.022, 035
Regency.....	.017
Rembrandt .....	.003
Samsung .....	.034
Scientific Atlanta .....	.006, 036, 037, 038
Signal .....	.018
Signature .....	.003
Sprucer .....	.000
Standard Component.....	.039, 044
Starcom .....	.001, 007, 018
Stargate.....	.018
Starquest.....	.018
Tocom .....	.004, 023
Tusa.....	.018
TV86.....	.027
Unika .....	.008, 009, 011
United Cable.....	.001
Universal .....	.008, 009, 010, 011
Video Way .....	.044
View Star .....	.015, 016, 025, 027
Zenith .....	.000, 050, 051

## Audio System Codes

Aiwa .....	.250, 251, 252, 253, 254, 255, 256, 268
Denon .....	.274
Harman Kardon .....	.267
JBL .....	.300
JVC .....	.257, 267, 301
Kenwood .....	.258
Koss .....	.302, 303
Onkyo .....	.269, 304
Optimus .....	.275
Panasonic .....	.270, 271, 305, 306
Philips.....	.307
Pioneer .....	.308
RCA .....	.259, 264, 265, 266, 309
Sherwood.....	.273
Sony.....	.260, 261, 272, 310, 312
Technics.....	.270, 271
Venturer.....	.311
Yamaha.....	.262, 263

## Laser Disc Player Codes

RCA.....	.133
----------	------

