



## Car Link Quick Reference Guide

### Installing the application

After having Car Link installed, follow the steps below to begin using your system.

1. Download the free Car Link application to your phone:

**Android:**

- i. Open the SMS with the link to download the application.
- ii. Select the link and follow the instructions. Android users will be taken to the Android Market place to download the app.

**BlackBerry:**

- i. Open the SMS with the link to download the application.
- ii. Select the link and follow the instructions. BlackBerry users will download the app directly from the link. The app will also be available in the BlackBerry AppWorld.

**iPhone:**

- i. Open the SMS with the link to download the application.
- ii. Select the link and follow the instructions. iPhone users will be taken to the iPhone App Store to download the app.

2. Launch the Car Link app and select "Create Account" from the menu.

- i. Enter your email as the ID and a password, you will then need to accept the End User Agreement to complete the account creation.

**Note:** The user will remain logged in unless manually logged out. After logging out the application will launch in Demo Mode until a user has logged in.

3. Add your Vehicle to the account. You will be prompted to add a vehicle upon completion of creating an account in step 2 above.


- i. Enter the 19 digit SIM number provided by the dealer.
- ii. Enter one time use, 4 digit code provided by the dealer.

**Note:** You will be able to add more vehicles to the account by selecting "Settings" and then selecting "Add New Vehicle" and following the steps above.

### Keypad Screen Quick Reference

Use the icons on the Keypad Screen to operate the Car Link features for your vehicle. For more information and updates please visit the Car Link website, [voxxcarlink.com](http://voxxcarlink.com).

**Note:** Once a feature is activated, the length of time your vehicle takes to respond will be affected by cellular coverage or network congestion.



Touch this icon to lock the vehicle.



Touch this icon to unlock the vehicle.



Touch this icon to locate the vehicle.



Touch this icon to remote start the vehicle. The vehicle will remain running for the preprogrammed run time set by the installation center.

**AUX 1**

Touch this icon to activate AUX 1, if equipped.

**AUX 2**

Touch this icon to activate AUX 2, if equipped.