

Code Lists / Liste des codes / Lista de Códigos

Amplifier / Amplificateur / Amplificador

Durabrand	1561
Harman/Kardon	0892
JVC	0331
Left Coast	0892
Lenoxx	1561
Marantz	0892
Optimus	0823
Philips	0892
Pioneer	0823
Polk Audio	0892
RCA	0823
Sony	0815
Victor	0331
Yamaha	0354

Receiver / Récepteur / Receptor

Accurian	2098
Aiwa	1405, 0189, 0121, 1243, 1641
Akai	1512
Alco	1390
Anam	1609, 1074
Apex Digital	1257, 1430, 1774
Audiotronic	1189
Audiovox	1390
B & K	0701, 0820, 0840
Bose	1229, 0639, 1253, 1629, 1841, 1933
Cambridge Soundworks	1370, 2297
Carver	1189, 0189
Daewoo	1250
Denon	1360, 1142, 2279, 2857
Fisher	1801
Gateway	1517
Go Video	1532
Harman/Kardon	0189, 0891, 1304, 1306, 2241
Hitachi	1801
Insignia	1030, 1077, 1893, 2169, 2175
Integra	0135, 1298, 1320, 1805
JBL	1306
JVC	1374, 1676, 1871, 2239, 2331
Kenwood	1313, 1570, 1569, 0186
KLH	1390, 1412, 1428
Koss	1366
LG	1293, 2197
Linn	0189
Magnavox	1189, 1269, 0189, 0391, 1514
Marantz	1189, 1269, 0189, 1289
Mitsubishi	1393
Onkyo	0135, 0842, 1298, 1320, 1531, 1805
Optimus	1023, 0186, 1074
Oritron	1366
Panasonic	1308, 0367, 1288, 1316, 1548, 1633, 1763, 1764, 2967
Philips	1189, 1269, 0189, 0391, 1266, 1831, 2311
Pioneer	1023, 0244, 0630, 1123, 1384, 1935
Polaroid	1508
Polk Audio	0189, 1289
Proscan	1254
RCA	1023, 1609, 1254, 1074, 1123, 1390, 1511, 2041
Rio	1869

Samsung	1295, 1500, 1868
Sansui	0189
Sanyo	1251, 1469, 1801
Sharp	0186, 1286
Sherwood	1077, 1517, 1653, 1905, 2169
Sherwood Newcastle	2169
Sonic Blue	1532, 1869
Sony	1759, 1058, 1441, 1258, 1622, 1558, 1658, 1758, 1822, 1858, 2172
Stereophonics	1023
Sunfire	1313
Teac	1074, 1390, 1528
Technics	1308
Thorens	1189
Toshiba	1788
Venturer	1390
Vizio	1517
Wards	0189
Yamaha	0176, 0186, 0376, 1176, 1276, 1331, 1375, 1376, 1476, 1815, 2061
Zenith	0857, 1293

Audio Accessories / Accessoires de audio / Acessorios de audio

Accurian	1106
Altec Lansing	0607
Apple	1115, 1644
D-Link	1522
DLO	1155
GPX	2113
Griffin	1891
iDeck	1106
iLive	2113
Monitor Audio	1106
NaviPod	1644
Netgear	1785
Roku	1828
SSI	1522
Yamaha	1809, 1810

Cable / Câble

Amino	1602, 1822
Bright House	1376, 1877
Cable One	1376, 1877
Cablevision	1376, 1877
Charter	1376, 1877, 2187
Cisco	1877, 0877, 1982
Comcast	1376, 1877, 1982, 2576
Cox	1376, 1877
Digeo	1187, 2187
Director	0476
General Instrument	0476
Homecast	2301
i3 Micro	1602
Insight	1376, 1877
Jerrold	0476
Mediacom	1376, 1877
Motorola	1376, 0476, 1187
Myrio	1602, 1822
Pace	1877
Panasonic	1982
Pioneer	1877, 0877
Scientific Atlanta	1877, 0877
Sejin	1602
Suddenlink	1376, 1877
Time Warner	1376, 1877, 2187
Tivo	2576

Satellite / Satellite

Bell ExpressVu.....	0775, 1170
Chaparral.....	0216
Coolsat.....	1806
Crossdigital.....	1109
DirecTV.....	1377, 0392, 0566, 0639, 1639, 1142, 0247, 0749, 1749, 1856, 1076, 1109, 1189, 1414, 1442, 1443, 1609, 1708
Dish Network System.....	0775, 1505, 1170, 1775
Dishpro.....	0775, 1505, 1775
Echostar.....	0775, 1505, 1170, 1775
Expressvu.....	0775, 1775
GE.....	0566
General Instrument.....	0869
GOI.....	0775, 1775
Hitachi.....	1250
HTS.....	0775, 1775
Hughes Network Systems.....	1142, 0749, 1749, 1442, 1443
Humax.....	1790
JVC.....	0775, 1170, 1775
LG.....	1414
Mitsubishi.....	0749
Motorola.....	0869
Next Level.....	0869
Panasonic.....	0247, 0701, 1189
Pansat.....	1807
Philips.....	1142, 0749, 1749, 1076, 1442
Proscan.....	0392, 0566
RadioShack.....	0869
RCA.....	0566, 0143
Samsung.....	1377, 1276, 1109, 1442, 1609, 1708
Sony.....	0639, 1639
Star Choice.....	0869
Tivo.....	1142, 1442, 1443

Toshiba.....	0749, 1749, 0790
Ultrasat.....	1806
Voom.....	0869
Zenith.....	1856

Satellite-DVR Combos / Combinés Satellite - DVR / Combos de Satellite-DVR

Bell ExpressVu.....	0775, 1170
DirecTV.....	1377, 0392, 0639, 1142, 1076, 1442, 1443
Dish Network System.....	0775, 1505
Dishpro.....	0775, 1505
Echostar.....	0775, 1505, 1170
Expressvu.....	0775
Hughes Network Systems.....	1142, 1442, 1443
JVC.....	1170
Motorola.....	0869
Philips.....	1142, 1442
Proscan.....	0392
Samsung.....	1442
Sony.....	0639
Star Choice.....	0869
Tivo.....	1142, 1442, 1443

Cable-DVR Combos / Combinés Câble - DVR / Combos de Cable-DVR

Amino.....	1822
Bright House.....	1376, 1877
Cable One.....	1376, 1877
Cablevision.....	1376, 1877
Charter.....	1376, 1877, 2187
Cisco.....	1877, 1982
Comcast.....	1376, 1877, 1982, 2576
Cox.....	1376, 1877
Digeo.....	1187, 2187
Homecast.....	2301
Insight.....	1376, 1877
Mediacom.....	1376, 1877
Motorola.....	1376, 1187
Myrio.....	1822
Pace.....	1877
Panasonic.....	1982
Pioneer.....	1877
Scientific Atlanta.....	1877
Suddenlink.....	1376, 1877
Time Warner.....	1376, 1877, 2187
Tivo.....	2576

DVD / Lecteurs DVD

Accurian.....	0675, 1416
Advent.....	1016
Aiwa.....	0641
Akai.....	0695, 0770, 0899, 1089
Alco.....	0790
Allegro.....	0869
Amphion Media Works.....	0872, 1245
AMW.....	0872, 1245
Apex Digital.....	0672, 0717, 0755, 0794, 0796, 0797, 0830, 1004, 1056, 1061, 1100, 1480
Arrgo.....	1023
Aspire Digital.....	1168, 1407
Astar.....	1489, 1678
Audiovox.....	0790, 1121, 1122
B & K.....	0662
BBK.....	1224
Bel Canto Design.....	1571
Blaupunkt.....	0717
Blue Parade.....	0571
Bose.....	2023
Broksonic.....	0695, 0868, 1419
Buffalo.....	1882
Centrios.....	1577
Cinea.....	0831
CineVision.....	0876, 0833, 0869
Citizen.....	0695, 1277
Coby.....	0778, 0852, 1086, 1107, 1165, 1177, 1351
Craig.....	0831
Curtis Mathes.....	1087
CyberHome.....	0816, 0874, 1023, 1024, 1117, 1129, 1502, 1537
D-Link.....	1881
D-Vision.....	1173

Daewoo.....	0784, 0705, 0833, 0869, 1169, 1172, 1234, 1242, 1441, 1443	Onkyo.....	0503, 0627, 1769, 2120, 2147
Denon.....	0490, 0634, 2258	Oppo.....	0575, 1224, 2185
Desay.....	1407	OptoMedia Electronics.....	0896
Diamond Vision.....	1316, 1609, 1610	Oritron.....	0651
DigitalMax.....	1738	Panasonic.....	0490, 0632, 0703, 1362, 1462, 1490, 1641, 1762
Disney.....	0675, 1270	Philco.....	0675
Dual.....	1068, 1085	Philips.....	0503, 0539, 2056, 0646, 0675, 0854, 1260, 1267, 1340, 1354, 2084, 2334, 2434
Durabrand.....	1127, 2164	Pioneer.....	0525, 0571, 0142, 0631, 0632, 1460, 1571, 2442
DVD2000.....	0521	Polaroid.....	1061, 1086, 1245, 1261, 1316, 1478, 1480, 1482, 2313
Emerson.....	0591, 0675, 0821, 1268	Polk Audio.....	0539
Enterprise.....	0591	Portland.....	0770
ESA.....	0821, 1268, 1443	Presidian.....	0675, 1738
Fisher.....	0670, 1919	Prima.....	1016
Funai.....	0675, 1268, 1334	Primare.....	1467
Gateway.....	1073, 1077, 1158	Princeton.....	0674
GE.....	0522, 0815, 0717	Proscan.....	0522
GFM.....	0675, 1268	ProVision.....	0778
Go Video.....	0744, 0715, 0741, 0783, 0833, 0869, 1044, 1075, 1099, 1144, 1158, 1304, 1443, 1730	Qwestar.....	0651
GoldStar.....	0741	RCA.....	0522, 0571, 0717, 0790, 0822, 1022, 1132, 1193, 1769
GPX.....	0699, 0769	Rio.....	0869
Greenhill.....	0717	RJTech.....	1360
Harman/Kardon.....	0582, 0702, 1229	Rotel.....	0623
Helios.....	2192	Sampo.....	0698, 0752, 1501
Hello Kitty.....	0831	Samsung.....	0490, 0573, 0199, 0899, 1044, 1075, 2329
Hitachi.....	0573, 0664, 1247, 1919	Sansui.....	0695
Hiteker.....	0672	Sanyo.....	0670, 0695, 0873, 1919
Humax.....	1588	Schmartz.....	2367
iLo.....	1348, 1472	Sensory Science.....	1158
Initial.....	0717, 1472	Sharp.....	0630, 0675, 0752, 1256, 2250
Insignia.....	0675, 1268, 2095, 2428	Sharper Image.....	1117
Integra.....	0627, 1769, 2147	Sherwood.....	0633, 0770, 1043, 1077, 1889
JBL.....	0702	Sherwood Newcastle.....	1077
Jensen.....	1016	Shinsonic.....	0533, 0839
JSI.....	1423	Sigma Designs.....	0674
JVC.....	0558, 0623, 0867, 1164, 1275, 1550, 1602, 1863	Sonic Blue.....	0869, 1099
jWin.....	1049	Sony.....	0533, 1533, 0864, 0772, 1033, 1070, 1431, 1432, 1433, 1516, 1548, 1892, 2043
Kawasaki.....	0790	Sova.....	1122
Kenwood.....	0490, 0534, 0682	Sungale.....	1074
KLH.....	0717, 0790, 1149, 1261	Superscan.....	0821
Konka.....	0711, 0719, 0720	SVA.....	0860, 1105
Koss.....	0651, 0896, 1423	Sylvania.....	0675, 0821, 1268, 2194
Lasonic.....	0798, 1173	Symphonic.....	0675, 0821
Lenoxx.....	1127	Teac.....	0790
LG.....	0591, 0741, 0869, 1526	Technics.....	0490, 0703
LiteOn.....	1058, 1158, 1416, 1440, 1656, 1738	Terapin.....	1031
Loewe.....	0511	Theta Digital.....	0571
Magnavox.....	0503, 0539, 0646, 0675, 0821, 1268, 1354, 1472, 1506	Tivo.....	1503
Malata.....	0782	Toshiba.....	0503, 0695, 1045, 1154, 1503, 1510, 1588, 1769, 1854, 2277
Marantz.....	0539, 2414	Tredex.....	0800, 0803
McIntosh.....	1273	Urban Concepts.....	0503
Memorex.....	0695, 0831, 1270, 2213	US Logic.....	0839
Microsoft.....	0522, 2083	Venturer.....	0790
Mintek.....	0839, 0717, 1472	Vizio.....	1064, 1226
Mitsubishi.....	1521, 0521	Vocopro.....	1360
NAD.....	0741	Xbox.....	0522, 2083
NEC.....	0785	Yamaha.....	0490, 0539, 0545
Nesa.....	0717	Zenith.....	0503, 0591, 0741, 0869
NexxTech.....	1402	Zoece.....	1265
Norcent.....	1003, 0872, 1107, 1265, 1457		
Olevia.....	2331		

DVD-R	
Accurian.....	0675, 1416
Apex Digital.....	1056
Aspire Digital.....	1168
Astar.....	1489
Broksonic.....	1419
Coby.....	1086
CyberHome.....	1129, 1502
DigitalMax.....	1738
Funai.....	0675, 1334
Gateway.....	1073, 1158
Go Video.....	0741, 1158, 1304, 1730
Humax.....	1588
iLo.....	1348
JVC.....	1164, 1275
LG.....	0741
LiteOn.....	1158, 1416, 1440, 1738
Magnavox.....	0646, 0675, 1506
Panasonic.....	0490
Philips.....	0646, 1340
Pioneer.....	0631, 1460
Polaroid.....	1086
Presidian.....	1738
RCA.....	0522
Samsung.....	0490
Sanyo.....	0670
Sensory Science.....	1158
Sharp.....	0675
Sony.....	1033, 1070, 1431, 1432, 1433
Sylvania.....	0675
Toshiba.....	1510, 1588, 2277
Zenith.....	0741

TV-VCR-DVD Combos / Combinés téléviseur - lecteur DVD / Combos de TV-VCR-DVD	
Controlled by TV / Contrôlé par TV / Controlado por TV	
Akai.....	1903
Broksonic.....	1938
Diamond Vision.....	1996
Emerson.....	1944
ESA.....	1944
Insignia.....	2088
Magnavox.....	1944
Panasonic.....	1946, 1947
Polaroid.....	1992
RCA.....	1953
Sylvania.....	1944
Symphonic.....	1944
Toshiba.....	1945
Controlled by DVD / Contrôlé par DVD / Controlado por DVD	
Akai.....	0899
Broksonic.....	0868
Diamond Vision.....	1609
Emerson.....	0821
ESA.....	0821
Funai.....	1334
Magnavox.....	0821
Panasonic.....	1362, 1462
Polaroid.....	1482
RCA.....	1132
Sharp.....	0630
Superscan.....	0821
Sylvania.....	0821
Symphonic.....	0821
Toshiba.....	1045
Controlled by VCR / Contrôlé par VCR / Controlado por VCR	
Sharp.....	0807

TV/DVD Combos / Combinés téléviseur - lecteur DVD / Combos de TV-DVD	
Controlled by TV / Contrôlé par TV / Controlado por TV	
Accurian.....	1803
Advent.....	1933
Akai.....	1675, 1935, 2232
Apex Digital.....	1943, 1991
Audiovox.....	1937, 1951, 1952
Axion.....	1937
Broksonic.....	1935
Cinego.....	1986
Citizen.....	1935
Diamond Vision.....	1997
Dynex.....	2049, 2184
Emerson.....	1864, 1394, 1963
ESA.....	1963
Funai.....	1963
GFM.....	1963
Hitachi.....	1960
iLo.....	1990
Initial.....	1990
Insignia.....	1963, 2002, 2049
Jensen.....	1933
KLH.....	1962
LG.....	1423, 1993
Magnavox.....	1866, 1963, 1990
Mintek.....	1990
Panasonic.....	1941
Polaroid.....	1523, 1766, 1769, 1962, 1991, 2002
Prima.....	1933
Proscan.....	2256
RCA.....	1948, 1958, 2002, 2187
Samsung.....	1903
Sansui.....	1935
Sharp.....	0818
Sova.....	1952
Sylvania.....	1864, 1394, 1886, 1963
Toshiba.....	1524, 1635, 1935
TruTech.....	2066
Controlled by DVD / Contrôlé par DVD / Controlado por DVD	
Advent.....	1016
Akai.....	0695
Apex Digital.....	0830, 1480
Audiovox.....	1121, 1122
Broksonic.....	0695
Citizen.....	0695
Diamond Vision.....	1610
Emerson.....	0675, 1268
ESA.....	1268
Funai.....	1268
GFM.....	1268
Hitachi.....	1247
iLo.....	1472
Initial.....	1472
Insignia.....	1268
Jensen.....	1016
KLH.....	1261
Konka.....	0719, 0720
LG.....	1526
Magnavox.....	1268, 1472
Mintek.....	1472
Panasonic.....	1490
Philips.....	0854, 1260
Polaroid.....	1261, 1480
Prima.....	1016
RCA.....	1022, 1193
Samsung.....	0899
Sansui.....	0695
Sova.....	1122
Sylvania.....	0675, 1268, 2194
Toshiba.....	0695

VCRs / Magnétoscopes

ABS.....	1972
Accurian.....	0000
Admiral.....	0209
Adventura.....	0000
Aiwa.....	0000
Alienware.....	1972
Asha.....	0240
Beaumarck.....	0240
Bell & Howell.....	0104
Bell ExpressVu.....	1944
Broksonic.....	0184, 0121, 0209, 0002, 1479, 1815
CCE.....	0072
Citizen.....	1278
Colt.....	0072
Craig.....	0047, 0240, 0072
Curtis Mathes.....	0060, 0162, 1035
Cybernex.....	0240
CyberPower.....	1972
Daewoo.....	1278
Dell.....	1972
Denon.....	0042
DirecTV.....	0739, 0740
Dish Network System.....	1944
Dishpro.....	1944
Durabrand.....	0039, 0038
Dynatech.....	0000
Echostar.....	1944
Emerson.....	0184, 0000, 0121, 0043, 0209, 0002, 0593, 1278, 1479, 1593
Expressvu.....	1944
Fisher.....	0047, 0104
Fuji.....	0033
Funai.....	0000, 0593, 1593
Garrard.....	0000
Gateway.....	1972
GE.....	0060, 0240, 0807, 1035, 1060
GFM.....	1593
Go Video.....	0432, 0614
GOI.....	1944
GoldStar.....	0038, 1237
Gradiente.....	0000
Harley Davidson.....	0000
Harman/Kardon.....	0038
Harwood.....	0072
Hewlett Packard.....	1972
HI-Q.....	0047
Hitachi.....	0000, 0042, 0089
Howard Computers.....	1972
HP.....	1972
HTS.....	1944
Hughes Network Systems.....	0739, 0042, 0740
Humax.....	0739
Hush.....	1972
iBUYPOWER.....	1972
JVC.....	0067, 1707, 1944
Kenwood.....	0067, 0038
KLH.....	0072
LG.....	1037
Linksys.....	1972
Lloyd's.....	0000
Logik.....	0072
Magnasonic.....	0593, 1278
Magnavox.....	0039, 0000, 0563, 0593, 1593, 1781
Magnin.....	0240
Matsushita.....	0162, 1162
Media Center PC.....	1972
Memorex.....	0162, 0039, 0047, 0240, 0000, 0104, 0209, 1037, 1162, 1237, 1262
MGA.....	0240, 0043
MGN Technology.....	0240

Microsoft.....	1972
Mind.....	1972
Minolta.....	0042
Mitsubishi.....	0067, 0043, 0807
MTC.....	0240, 0000
Multitech.....	0000, 0072
NEC.....	0104, 0067, 0038
Niveus Media.....	1972
Noblex.....	0240
Northgate.....	1972
Optimus.....	1062, 0162, 0104, 0432, 0593, 1048, 1162, 1262
Orion.....	0184, 0209, 0002, 1479
Panasonic.....	1062, 0162, 0225, 0614, 0616, 1035, 1162, 1262
Penney.....	0240, 0042, 0038, 1035, 1237
Pentax.....	0042
Philips.....	0739, 0618, 1081, 1181
Pioneer.....	0067
Presidian.....	1593
Profitronic.....	0240
Proscan.....	0060, 1060
Protec.....	0072
Pulsar.....	0039
Quasar.....	0162, 1035, 1162
RadioShack.....	0000, 1037
RCA.....	0060, 0240, 0042, 0807, 0880, 1035, 1060
Realistic.....	0047, 0000, 0104
ReplayTV.....	0614, 0616
Ricavision.....	1972
Runco.....	0039
Samsung.....	0739, 0240, 1014
Sanky.....	0039
Sansui.....	0000, 0067, 0209, 1479
Sanyo.....	0047, 0240, 0104
Scott.....	0184, 0121, 0043
Sears.....	0047, 0000, 0042, 0104, 1237
Sharp.....	0807, 0848
Shintom.....	0072
Shogun.....	0240
Singer.....	0072
Sonic Blue.....	0614, 0616
Sony.....	1232, 0033, 0000, 0636, 1032, 1972
Stack 9.....	1972
STS.....	0042
Sylvania.....	0000, 0043, 0593, 1593, 1781
Symphonic.....	0000, 0593, 1593
Systemax.....	1972
Tagar Systems.....	1972
Teac.....	0000
Technics.....	0162
Teknika.....	0000
Thomas.....	0000
Tivo.....	0739, 0618, 0636, 0740, 1996
TMK.....	0240
Toshiba.....	0043, 0845, 1008, 1145, 1972, 1996
Totevision.....	0240
Touch.....	1972
Unitech.....	0240
Vector Research.....	0038
Videosonic.....	0240
Viewsonic.....	1972
Villain.....	0000
Voodoo.....	1972
Wards.....	0060, 0047, 0240, 0000, 0042, 0072
White Westinghouse.....	0209, 0072
XR-1000.....	0000, 0072
Yamaha.....	0038
Zenith.....	0039, 0033, 0000, 0209, 1139, 1479
ZT Group.....	1972

TV/VCR Combos / Combinés téléviseur
-magnétoscope / Combos de TV-VCR

Controlled by TV / Contrôlé par TV /	
Controlado por TV	
America Action.....	0180
Audiovox.....	0180
Emerson.....	0236
Controlled by VCR / Contrôlé par VCR /	
Controlado por VCR	
Broksonic.....	0002, 1479
Citizen.....	1278
Colt.....	0072
Curtis Mathes.....	1035
Daewoo.....	1278
Emerson.....	0002, 0593, 1278, 1479
Funai.....	0000
GE.....	0240, 0807, 1035, 1060
GoldStar.....	1237
Harley Davidson.....	0000
Hitachi.....	0000
LG.....	1037
Lloyd's.....	0000
Magnasonic.....	0593, 1278
Magnavox.....	0000, 0593, 1781
Magnin.....	0240
Memorex.....	0162, 1037, 1162, 1237, 1262
MGA.....	0240
Mitsubishi.....	0807
Optimus.....	0162, 0593, 1162, 1262
Orion.....	0002, 1479
Panasonic.....	0162, 1035, 1162, 1262
Penney.....	0240, 1035, 1237
Quasar.....	0162, 1035, 1162
RadioShack.....	0000, 1037
RCA.....	0240, 0807, 1035, 1060
Samsung.....	1014
Sansui.....	0000, 1479
Sanyo.....	0240
Sears.....	0000, 1237
Sony.....	1232, 0000
Sylvania.....	1781
Symphonic.....	0000, 0593
Thomas.....	0000
Toshiba.....	0845, 1145
Zenith.....	0000, 1479

DVRs

ABS.....	1972
Alienware.....	1972
Bell ExpressVu.....	1944
CyberPower.....	1972
Dell.....	1972
DirectTV.....	0739, 0740
Dish Network System.....	1944
Dishpro.....	1944
EchoStar.....	1944
ExpressVu.....	1944
Gateway.....	1972
Go Video.....	0614
GOI.....	1944
Hewlett Packard.....	1972
Howard Computers.....	1972
HP.....	1972
HTS.....	1944
Hughes Network Systems.....	0739, 0740
Humax.....	0739
Hush.....	1972
iBUYPOWER.....	1972
JVC.....	1944
Linksys.....	1972
Media Center PC.....	1972
Microsoft.....	1972
Mind.....	1972
Niveus Media.....	1972
Northgate.....	1972
Panasonic.....	0614, 0616
Philips.....	0739, 0618
RCA.....	0880
ReplayTV.....	0614, 0616
Samsung.....	0739
Sonic Blue.....	0614, 0616
Sony.....	0636, 1972
Stack 9.....	1972
Systemax.....	1972
Tagar Systems.....	1972
Tivo.....	0739, 0618, 0636, 0740
Toshiba.....	1008, 1972, 1996
Touch.....	1972
Viewsonic.....	1972
Voodoo.....	1972
ZT Group.....	1972

DTV Converters /
Récepteurs TV numériques /
Convertidores Digitales

Access HD.....	2185
Airlink 101.....	2491
Alpha Digital.....	2185
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
CASTi.....	2305
Channel Master.....	2365
Coship.....	2487
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network System.....	2470
EchoStar.....	2470
Evolution.....	2479
GE.....	2360, 2450
Goodmind.....	2450

Gridlink.....	2348
Insignia.....	1415
Lasonic.....	2348
Magnavox.....	1563
Memorex.....	2486
MicroGEM.....	2489
Philco.....	1563
RCA.....	2325, 2454
Sansonic.....	2348
Sylvania.....	1563
Tivax.....	2185
Ventura.....	2454
Venturer.....	2454
Winegard.....	2454
Zenith.....	1415
Zentech.....	2491
Zinwell.....	2488

Video Accessories / Accessoires de vidéo / Accessoires de vídeo		
ABS.....	1272	
Access HD.....	2185	
ADB.....	2254, 2586	
Airlink 101.....	2491	
Alienware.....	1272	
Alpha Digital.....	2185	
Amino.....	1481, 2482	
AMTC.....	2185	
Apex Digital.....	2478	
Artec.....	2490	
AT&T.....	0858	
CASTI.....	2305	
Channel Master.....	2365	
Cisco.....	2345	
Coship.....	2487	
CyberPower.....	1272	
Daewoo.....	2338	
Daytek.....	2305	
Digital Stream.....	2303	
Dish Network System.....	2470	
Echostar.....	2470	
Entone.....	2302	
Epson.....	1563	
Evolution.....	2479	
Gateway.....	1272	
GE.....	2360, 2450	
Goodmind.....	2450	
Gridlink.....	2348	
Hewlett Packard.....	1272	
Howard Computers.....	1272	
HP.....	1272	
Hush.....	1272	
iBUYPOWER.....	1272	
Insignia.....	1415	
KoolConnect.....	1481	
Lasonic.....	2348	
LG.....	1415	
Linksys.....	1272	
Magnavox.....	1563	
Media Center PC.....	1272	
Memorex.....	2486	
MicroGEM.....	2489	
Microsoft.....	1272	
Mind.....	1272	
Motorola.....	1998, 0858, 2378	
Niveus Media.....	1272	
Northgate.....	1272	
Philco.....	1563	
RCA.....	2325, 2454	
Ricavision.....	1272	
Roku.....	2371	
Sansonic.....	2348	
Scientific Atlanta.....	0858, 2345	
Sony.....	1272, 1324	
Stack 9.....	1272	
SureWest.....	1481	
Sylvania.....	1563	
Systemax.....	1272	
Tagar Systems.....	1272	
Tivax.....	2185	
Toshiba.....	1272	
Touch.....	1272	

Ventura.....	2454
Venturer.....	2454
Verizon.....	2378
Viewsonic.....	1272
Voodoo.....	1272
Vudu.....	2298
Winegard.....	2454
Zenith.....	1415
Zentech.....	2491
Zinwell.....	2488
ZT Group.....	1272

TVs / Téléviseurs

Accurian.....	1803
Action.....	0873
Admiral.....	0093, 0463
Advent.....	0761, 0783, 0815, 0817, 0842, 1933
Aiko.....	0092
Akai.....	0812, 1675, 0702, 0030, 0672, 1207, 1676, 1903, 1935, 2078, 2232
Albatron.....	0700, 0843
America Action.....	0180
Ampro.....	0751
Anam.....	0180
AOC.....	0030, 1365, 1590, 2014
Aomni.....	1623
Apex Digital.....	0748, 0879, 0765, 0767, 0890, 1217, 1943, 1991
Astar.....	1548
Audiovox.....	0451, 0180, 0092, 0623, 0710, 0802, 0846, 0875, 1284, 1937, 1951, 1952
Aventura.....	0171
Axion.....	1937
Bell & Howell.....	0154
BenQ.....	1032, 1315
Bradford.....	0180
Broksonic.....	0236, 0463, 1935, 1938
Byd:sign.....	1309, 1311
Cadia.....	1283
Candle.....	0030
Carnivale.....	0030
Carver.....	0054
Celebrity.....	0000
Celera.....	0765
Changhong.....	0765
Cinego.....	1986
Citizen.....	0060, 0030, 0092, 1935
Clarion.....	0180
Coby.....	2017
Commercial Solutions.....	1447, 0047
Contec.....	0180
Craig.....	0180
Crosley.....	0054
Crown.....	0180
Curtis Mathes.....	0047, 0054, 0154, 0451, 0093, 0060, 0702, 0030, 0145, 0166, 0466, 1147, 1347
CXC.....	0180
CyberHome.....	0794
Cytron.....	1326

Daewoo.....	0451, 0092, 1661, 0623, 0661, 0672	LXI.....	0047, 0054, 0154, 0156, 0178
Dell.....	1264, 1080, 1178, 1403, 1863	MAG.....	1498, 1687
Denon.....	0145	Magnavox.....	1454, 1866, 0054, 0030, 0706, 0802, 1198, 1254, 1365, 1525, 1944, 1963, 1990
Diamond Vision.....	1996, 1997	Marantz.....	0054, 0030, 0704, 0854, 0855, 1154, 1398
Digital Lifestyles.....	1765	Matsushita.....	0250, 0650
Dumont.....	0017	Maxent.....	1755, 0762, 1211, 1757
Durabrand.....	0463, 0180, 0178, 0171, 1034	Megapower.....	0700
Dwin.....	0720	Megatron.....	0178, 0145
Dynex.....	1463, 2049, 2184	Memorex.....	0154, 0463, 0150, 0178
Electroband.....	0000	MGA.....	0150, 0178, 0030
Electrograph.....	1755, 1623	Midland.....	0047, 0017, 0051
Electrohome.....	0463	Mintek.....	1603, 1990
Element.....	1687	Mitsubishi.....	1250, 0093, 0150, 0178, 0836, 0868, 1550
Emerson.....	1864, 0154, 0236, 0463, 0180, 0178, 0171, 0623, 1394, 1665, 1944, 1963	Monivision.....	0700, 0843
Emprex.....	1422, 1546, 1765	Motorola.....	0093, 0835
Envision.....	0030, 0813, 1365, 2014	Moxell.....	0835
Epson.....	0833, 0840, 1290	MTC.....	0060, 0030
ESA.....	0812, 0171, 1944, 1963	Multitech.....	0180
Fisher.....	0154	NAD.....	0156, 0178, 0866, 1156
FlexVision.....	0710	NEC.....	0030, 0497, 0882, 1398, 1704
Fujitsu.....	0809, 0683, 0853, 2008	NetTV.....	1755, 0762
Funai.....	0180, 0171, 1271, 1963	Nexus Electronics.....	2183
Futuretech.....	0180	Nikko.....	0178, 0030, 0092
Gateway.....	1755, 1001, 1002, 1003, 1756	Norcent.....	0748, 0824, 1089, 1365, 1589, 1590, 1591
GE.....	1447, 0047, 0051, 0451, 0178, 1347	Norwood Micro.....	1286, 1296, 1303
GFM.....	0171, 1665, 1963, 2167	NTC.....	0092
Gibraltar.....	0017, 0030	NuVision.....	1657, 2158
Go Video.....	0886	Olevia.....	1610, 1144, 1240, 1331
GoldStar.....	0178, 0030	Olympus.....	1342
Grunpy.....	0180	Onwa.....	0180
Haier.....	1034, 1748, 1749	Optimus.....	0250, 0154, 0166, 0650
Hallmark.....	0178	Optoma.....	0887
Hannspree.....	1348, 1351, 1352	Optonica.....	0093
Harman/Kardon.....	0054	Orion.....	0236, 0463, 1463
Harsper.....	1206	Panasonic.....	0250, 1480, 0051, 0650, 1291, 1941, 1946, 1947
Harvard.....	0180	PARAK.....	2194, 2202
Havermy.....	0093	Penney.....	0047, 0156, 0051, 0060, 0178, 0030, 1347
Helios.....	0865	Petters.....	1523
Hello Kitty.....	0451	Philco.....	0054, 0030
Hewlett Packard.....	1494, 1088, 1089, 1101, 1502	Philips.....	1454, 0054, 0690, 1154, 1483, 1744, 1867
Hisense.....	0748	Pilot.....	0030
Hitachi.....	1643, 1145, 0145, 0797, 1960	Pioneer.....	1457, 0166, 0679, 0866, 1260, 1398
HP.....	1494, 1088, 1089, 1101, 1502	Planar.....	1496
Hyundai.....	0849, 1219, 1294	Polaroid.....	1523, 0765, 2121, 2120, 2119, 2002, 1992, 1991, 1962, 1769, 1767, 1766, 1687, 1498, 1341, 1328, 1327, 1326, 1316, 1314, 1286, 1276, 1262, 0865
iLo.....	1286, 1603, 1665, 1684, 1990	Portland.....	0092
Infinity.....	0054	Prima.....	0761, 0783, 0815, 0817, 1933
Initial.....	1603, 1990	Princeton.....	0700
Insignia.....	1564, 0171, 1204, 1326, 1517, 1963, 2002, 2049, 2088	Prism.....	0051
Inteq.....	0017	Proscan.....	1447, 0047, 1347, 2147, 2256
iRIS.....	2189	Proton.....	0178, 0466
JBL.....	0054	Prottron.....	1320, 1323
JCB.....	0000	Proview.....	0835, 1498, 1687
Jensen.....	0761, 0815, 0817, 1299, 1933	Pulsar.....	0017
JVC.....	0053, 0731, 1253, 1601, 1774	Puneet.....	1546
KDS.....	1498, 1687	Quasar.....	0250, 0051, 0650
KEC.....	0180	RadioShack.....	0047, 0154, 0180, 0178, 0030
Kenwood.....	0030	RCA.....	1547, 1447, 0047, 0090, 0679, 1047, 1147, 1247, 1347, 1781, 1948, 1953, 1958, 2002, 2187, 2247
KLH.....	0765, 0767, 1962	Realistic.....	0154, 0180, 0178, 0030
Kost.....	1262, 1483	RevolutionHD.....	1623
KTV.....	0180, 0030		
LG.....	1423, 0178, 0700, 0856, 1178, 1325, 1768, 1993		

Runco	0017, 0030, 0497, 0603, 1398, 1629
Sampo	1755, 0030, 0762
Samsung	0812, 0060, 0702, 0178, 0030, 0766, 0814, 1060, 1575, 1903
Sansui	0463, 1409, 1935
Sanyo	0154, 0088, 0799, 0893, 1142
Sceptre	0878, 1217, 1360, 1599
Scotch	0178
Scott	0236, 0180, 0178, 1711
Sears	0047, 0054, 0154, 0156, 0178, 0171
Sharp	0818, 0093, 0491, 0688, 0689, 0851, 1602
Sheng Chia	0093
Sherwood	1399
Signet	1262
SIM2 Multimedia	1297
Sole	1483, 1623
Sony	0000, 0810, 0834, 1317, 1685
Soundesign	0180, 0178
Sova	1320, 1952
Soyo	1546, 1826
Spectroniq	1498, 1687
Squareview	0171
SSS	0180
Starlite	0180
Studio Experience	0843
Superscan	0093, 0864
Supreme	0000
SVA	0748, 0865, 0870, 0872
Sylvania	1864, 0054, 0030, 0171, 1271, 1314, 1394, 1665, 1886, 1944, 1963
Symphonic	0180, 0171, 1944
Syntax	1610, 1144, 1240, 1331
Tandy	0093
Tatung	1101, 1285, 1286, 1287, 1288, 1361, 1756
Technics	0250, 0051
Techview	0847
Techwood	0051
Teknika	0054, 0180, 0150, 0060, 0092
Telefunken	0702
TMK	0178
TNCi	0017
Toshiba	1524, 0154, 0156, 1256, 0060, 1945, 1935, 1704, 1656, 1635, 1356, 1343, 1325, 1306, 1156, 0845, 0832, 0650
TruTech	1723, 2066
TVS	0463
Ultra	1323
US Logic	1286, 1303
Vector Research	0030
Victor	0053
Vidikron	0054, 1398, 1629
Vidtech	0178
Viewsonic	1755, 0797, 0857, 0864, 0885, 1330, 1342, 1578, 1627, 1742, 2014, 2087
Viore	1207, 1684
Visart	1336
Vizio	1758, 0864, 0885, 1499, 1756
Wards	0054, 0178, 0030, 0866, 1156
Waycon	0156
Westinghouse	1712, 0885, 0889, 0890, 1282, 1577
White Westinghouse	0463, 0623
Wyse	1365
Yamaha	0030, 0769, 0797, 0833, 0839
Zenith	0017, 0463, 0178, 0092

DLP	
Hewlett Packard	1494
HP	1494
Magnavox	1525
Mitsubishi	1250
Optoma	0887
Panasonic	1291
RCA	1447
Samsung	0812, 1060
SIM2 Multimedia	1297
SVA	0872
Toshiba	1524, 1306
Vizio	1499

HDTV	
Advent	0842
Hitachi	1960
Marantz	0854
Mitsubishi	0150
Olevia	1610
Panasonic	0250, 0650, 1291
Pioneer	0679
RCA	1447
Samsung	0812, 0702
Sharp	0688, 0689
Toshiba	1256

LCD / ACL	
Accurian	1803
Action	0873
Akai	1675, 1676, 1935, 2232
AOC	1365, 2014
Aomni	1623
Apex Digital	0890, 1217
Astar	1548
Audiovox	0180, 0710, 0802, 0846, 0875, 1284, 1937, 1951, 1952
BenQ	1315
Byd:sign	1309, 1311
Cadia	1283
Citizen	1935
Coby	2017
CyberHome	0794
Dell	1264, 1080, 1178, 1863
Digital Lifestyles	1765
Dynex	2049, 2184
Element	1687
Emerson	1864, 1394, 1963
Emprex	1422, 1546, 1765
Envision	0813, 1365, 2014
FlexVision	0710
Funai	0171
GFM	2167
Go Video	0886
Haier	1748, 1749
Hannspree	1348, 1351
Harsper	1206
Hewlett Packard	1088
Hitachi	1643
HP	1088
Hyundai	0849, 1219, 1294
iLo	1286, 1603, 1684, 1990
Initial	1603, 1990

Insignia.....	1564, 1204, 1517, 2002, 2049
iRIS.....	2189
Jensen	1299
JVC.....	1601, 1774
Kost.....	1262
LG.....	1423, 0856, 1178, 1768, 1993
Magnavox.....	1866, 0802, 1198, 1365, 1990
Marantz.....	0855
Maxent.....	1755, 0762, 1211, 1757
Mintek.....	1603, 1990
Mitsubishi	1250
NetTV.....	0762
Nexus Electronics.....	2183
Norcent.....	1365, 1589, 1591
Norwood Micro	1286, 1296
NuVision.....	1657, 2158
Olevia.....	1610, 1144, 1240, 1331
Panasonic.....	1480, 0650, 1941
PARK.....	2194, 2202
Petters.....	1523
Philips.....	1454, 1483, 1744, 1867
Pioneer.....	1260
Planar.....	1496
Polaroid.....	1523, 1262, 1276, 1316, 1341, 1498, 1687, 1766, 1767, 1769, 2119, 2120, 2121
Proscan.....	2147, 2256
Protron.....	1320, 1323
Puneet.....	1546
RCA.....	0047, 1781, 1958, 2187, 2247
RevolutionHD	1623
Runco.....	1629
Sampo.....	1755, 0762
Samsung.....	0812, 0766, 0814, 1575
Sansui.....	1409
Sanyo.....	1142
Sceptre.....	0878, 1217, 1360, 1599
Scott.....	1711
Sharp.....	0818, 0093, 1602
Sherwood.....	1399
Signet.....	1262
Sole.....	1483, 1623
Sony.....	0810, 1685
Sova.....	1320
Soyo.....	1546, 1826
Superscan.....	0864
SVA.....	0870
Sylvania.....	1864, 0171, 1271, 1314, 1394, 1886
Symphonic.....	0171
Syntax.....	1610, 1144, 1240, 1331
Tatung.....	1286
Techview	0847
Toshiba.....	1524, 0845, 1343, 1635, 1656
TruTech.....	1723
Ultra.....	1323
US Logic.....	1286
Vidikron.....	1398, 1629
Viewsonic.....	0857, 0864, 0885, 1330, 1578, 1627, 1742, 2014, 2087
Viore.....	1684
Visart.....	1336
Vizio.....	1758, 0864, 0885, 1756
Westinghouse.....	1712, 0885, 0889, 0890, 1282, 1577
Wyse.....	1365

Plasma

Akai.....	0812, 1675, 1207, 2078
Albatron.....	0843
AOC.....	1590
Aomni.....	1623
BenQ.....	1032
Byd:sign.....	1311
Daewoo.....	0661
Dell.....	1264, 1863
Electrograph.....	1755, 1623
ESA.....	0812
Fujitsu.....	0809, 0683, 0853, 2008
Funai.....	1271
Gateway.....	1755, 1001, 1002, 1003, 1756
Haier.....	1748
Harsper.....	1206
Helios.....	0865
Hewlett Packard.....	1089, 1502
Hitachi.....	1643, 0797
HP.....	1089, 1502
iLo.....	1684
Insignia.....	1564
JVC.....	0731
LG.....	1423, 0178, 0856
Magnavox.....	1866
Marantz.....	0704, 1398
Maxent.....	1755, 1757
Mitsubishi	0836
Monivision.....	0843
Motorola.....	0835
Moxell.....	0835
NEC.....	1398, 1704
NetTV.....	1755
Nexus Electronics.....	2183
Norcent.....	0824, 1089, 1590
Norwood Micro	1303
Panasonic.....	0250, 1480, 0650
Philips.....	0690, 1744
Pioneer.....	1457, 0679, 1260, 1398
Polaroid.....	0865, 1276, 1327, 1328
Proview.....	0835
Puneet.....	1546
RevolutionHD	1623
Runco.....	1398
Sampo.....	1755
Samsung.....	0812
Sanyo.....	1142
Sole.....	1623
Sony.....	0000, 0810, 1317
Studio Experience.....	0843
SVA.....	0865
Sylvania.....	1271, 1394
Tatung.....	1101, 1285, 1287, 1288, 1756
Toshiba.....	0650, 1704
US Logic.....	1303
Viewsonic.....	1755, 0797
Viore.....	1207, 1684
Vizio.....	1758, 1756
Yamaha.....	0797
Zenith.....	0178

Trademark(s) © Registered

Marque(s) de commerce déposée(s)® Marca(s) Registrada(s)

SuperAtlas Codes 00