

Program codes/Códigos de programa

Admiral 002, 128, 183, 189
Advent 191, 258, 260, 275
Aventura 129
Aiko 014, 182
Aiwa 289, 290
Akai 003, 177, 195, 201, 202, 295
Albatron 218
Alleron 036
America Action 186
Amtron 186
Anam 186
Anam National 141, 142, 186
AOC 005, 130, 143, 177, 260, 274, 275
Apex 053, 172, 184, 192, 232, 250, 280
Audiovox 182, 186, 188, 207, 223, 234
Aventura 185

Belcor 274
Bell & Howell 002, 037, 198
Benq 204, 306
Bradford 186
Brilliant 236, 237, 238
Brockwood 274
Broksonic 186, 189, 200

Candle 005, 007, 129, 177, 274
Carnivale 177
Carver 181
Celebrity 003, 175
Celera 053, 192
Centurion 008
Changhong 053, 192
Citizen 005, 007, 014, 037, 080, 148, 177, 182, 186, 195, 198, 274
Clarion 186
Colortyme 005, 009, 274
Commercial Solutions 178
Concerto 005, 274
Contec 186
Contec/Cony 186
Craig 186
Crosley 181
Crown 045, 186
CTX 304
Curtis Mathes 001, 005, 013, 037, 080, 148, 156, 159, 177, 178, 181, 183, 188, 195, 196, 198, 199, 202, 205, 229, 274, 295
CXC 186
Cytron 309

Daewoo 005, 014, 015, 016, 095, 140, 182, 188, 201, 207, 233, 260, 274, 275
Daytron 005, 274
Dell 181
Denon 196
DiamondVision 243
Dimensia 001
Dumont 176, 245, 274
Durabrand 173, 185, 186, 189, 274
Dwin 183, 212, 214

Electroband 003, 175
Electrograph 193
Electrohome 003, 005, 017, 018, 274

Emerson 005, 019, 020, 021, 022, 023, 024, 025, 026, 027, 028, 029, 030, 031, 032, 033, 034, 035, 036, 037, 093, 132, 140, 149, 157, 161, 169, 174, 185, 186, 189, 198, 200, 207, 274
Envision 005, 177, 215, 274
ESA 185, 202

Fisher 037, 198
Fujitsu 036
Funai 036, 139, 185, 186
Futuretech 186

Gateway 193, 204
GE 21, 001, 005, 018, 039, 040, 053, 063, 122, 123, 135, 149, 163, 178, 179, 188, 229, 232, 249, 250, 274
Gibralter 042, 176, 177, 245, 274
Go Video 224
Goldstar 005, 041, 042, 116, 117, 177, 260, 274, 275
Grunpy 036, 186

Haier 173, 242
Hallmark 005, 274
Harman/Kardon 181
Harvard 186
Havermy 183
Hello Kitty 188
Hisense 190
Hitachi 005, 043, 044, 100, 101, 102, 103, 105, 107, 110, 111, 112, 155, 165, 166, 167, 168, 169, 196, 248, 274, 276, 284

IMA 186
Infinity 045, 181
Insignia 189, 244, 309
Inteq 176

Janeil 129
JBL 045, 181
JC Penney 001, 005, 007, 018, 039, 040, 042, 053, 063, 079, 080, 135, 163, 260, 274, 275
JCB 003, 175
Jensen 005, 191, 258, 260, 274, 275, 309
JVC 040, 044, 046, 047, 048, 118, 119, 136, 157, 180, 263, 264, 271, 287, 292, 296

Kawasho 003, 005, 274
KEC 186
Kenwood 005, 177, 274
KLH 053, 192, 232
Kloss Novabeam 049, 050, 129, 186
Konka 194
KTV 051, 132, 177, 186

LG 221, 260, 274, 275
Loewe 045
Logik 002
Luxman 005, 274
LXI 001, 005, 037, 045, 052, 053, 135, 147, 163, 178, 181, 184, 198, 274

Magnavox 005, 007, 045, 049, 050, 054, 055, 064, 097, 098, 099, 153, 154, 160, 170, 174, 177, 181, 210, 230, 234, 252, 253, 258, 259, 272, 274, 283
Majestic 002



Marantz 005, 043, 045, 057, 177, 181, 220, 230, 274
Matsushita 187
Maxent 193
Megatron 005, 043, 196, 274
Memorex 002, 005, 037, 139, 185, 189, 197, 198, 260, 274, 275, 283
MGA 005, 018, 058, 177, 197, 260, 274, 275
Midland 040, 135, 163, 176, 178, 179, 245
Minutz 039
Mitsubishi 005, 018, 058, 094, 183, 197, 217, 260, 262, 274, 275
Monivision 218
Montgomery Ward 002
Motorola 128, 183
MTC 005, 080, 177, 195, 260, 274, 275
Multitech 186
Multivision 061

NAD 005, 052, 053, 137, 155, 184, 274, 291
NEC 005, 009, 177, 206, 260, 274, 275
Net-TV 193
Nikko 005, 014, 177, 182, 274
Norcent 190
NTC 014, 182

Olevia 239, 240
Onwa 186
Optimus 137, 155, 187, 198, 199
Optoma 225
Optonica 071, 128, 183
Orion 029, 189, 200

Panasonic 040, 045, 125, 179, 187, 254, 257, 288, 299, 301
Penney 001, 177, 178, 179, 184, 195, 229, 274
Philco 005, 007, 045, 049, 050, 054, 177, 181, 260, 274, 275, 283
Phillips 007, 045, 049, 050, 054, 062, 063, 064, 065, 181, 185, 209, 230, 252, 258, 261, 267, 269, 272, 273, 274, 277, 278, 281, 285, 286, 297, 300, 305
Philips Magnavox 181, 185, 230, 253, 258, 270, 273, 279
Pilot 177, 274
Pioneer 005, 066, 067, 068, 137, 155, 169, 171, 199, 274, 291, 294
Polaroid 053, 192
Portland 005, 014, 182, 260, 274, 275
Price Club 080
Prima 191, 258, 260, 275
Princeton 211
Prism 040, 179
Proscan 001, 135, 163, 178, 229, 249
Proton 005, 069, 205, 274
Proview 241
Pulsar 176, 245, 274

Quasar 040, 051, 070, 125, 179, 187, 254, 257

Radio Shack 001, 037, 177, 178, 186, 198, 274
Radio Shack/Realistic 001, 005, 037, 071, 186, 198, 274
RCA 000, 001, 005, 072, 073, 074, 075, 076, 077, 078, 135, 138, 140, 144, 150, 156, 159, 162, 163, 169, 171, 178, 229, 246, 249, 260, 274, 275, 293, 302
Realistic 001, 037, 177, 186, 198, 274
Runco 176, 177, 206, 245

Sampo 005, 177, 193, 274
Samsung 005, 013, 079, 080, 145, 177, 195, 202, 213, 216, 227, 255, 256, 260, 266, 274, 275, 282, 295

Sansui 189
Sanyo 037, 082, 083, 124, 198, 268, 274
Scotch 005, 274
Scott 005, 020, 029, 036, 186, 200, 274
Sears 001, 005, 036, 037, 047, 052, 053, 084, 135, 139, 163, 178, 181, 184, 185, 198, 232, 274
Sharp 005, 021, 071, 085, 087, 092, 128, 183, 208, 274, 298
Sheng Chia 183
Shogun 274
Signature 002, 019
Simpson 007
Sony 003, 146, 151, 152, 175, 228, 247, 251, 303, 308
Soundesign 005, 007, 036, 186, 274
Squareview 139, 185
SSS 186, 274
Starlite 186
Studio Experience 218
Superscan 183
Supre-Macy 129
Supreme 003, 175
SVA 242
Sylvania 005, 007, 045, 049, 050, 054, 055, 064, 088, 121, 139, 174, 177, 181, 185, 274, 307
Symphonic 027, 139, 185, 186
Syntax 239, 240

Tandy 128, 183
Tatung 204
Technics 040, 179, 187
Techview 219
Techwood 005, 040, 179, 274
Teknika 002, 005, 007, 014, 036, 055, 080, 125, 181, 182, 186, 195, 197, 260, 274, 275
Telefunken 202, 295
TMK 005, 274
TNCi 176
Toshiba 037, 052, 053, 080, 090, 121, 184, 195, 198, 231, 232, 265, 274
TVS 189

Universal 039, 063

V Inc. 235
Vector Research 177
Victor 047, 136, 180
Vidikron 181
Vidtech 005, 260, 274, 275
Viewsonic 193, 222, 235
Viking 129
Vizio 204, 235

Wards 001, 002, 005, 020, 027, 036, 039, 045, 049, 050, 054, 055, 063, 064, 071, 091, 177, 181, 231, 260, 274, 275, 291

Waycon 184
Westinghouse 175, 188, 226, 235
White Westinghouse 140, 189, 207

Yamaha 005, 177, 260, 274, 275

Zenith 002, 113, 114, 115, 176, 182, 189, 245, 248, 274