

## 12 Month Limited Warranty

Audiovox Electronics Corporation (the company) warrants to the original purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 12 months from the date of original purchase, such defect(s) will be repaired or replaced with reconditioned product (at the company's option) without charge for parts and repair labor. To obtain repair or replacement within the terms of this warranty, the product along with any accessories included in the original packaging is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of the defect(s), transportation prepaid, to the company at the address shown below. **DO NOT RETURN THIS PRODUCT TO THE RETAILER.**

The warranty does not extend to costs incurred for the installation, removal or reinstallation of the product.

The warranty does not apply to any product or part thereof which, in the opinion of the company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). **THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.**

This warranty is in lieu of all other express warranties or liabilities. **ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HERUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 18 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY.** No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation if incidental or consequential damage so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

**For customer service and technical information:: 1.800.290.6650**

TERK and the TERK logo are registered trademarks of AUDIOVOX Corp.  
Audiovox Electronics Corporation, 150 Marcus Blvd., Hauppauge, NY 11788



For Customer Service  
Visit Our Website At  
[www.terk.com](http://www.terk.com)  
Product Information, Photos,  
FAQ's, Owner's Manuals

57P008B


# TV4

## OWNER'S MANUAL



TV4  
Indoor Television Antenna






## About Your TERK TV4

TV4

Thank you for choosing the TERK TV4. TERK antennas are designed to help deliver sharp, clear video reception. At TERK, our engineering department is dedicated to designing antennas that enhance both the latest technology and the aesthetics of any viewing environment. The TV4 installs in minutes, is easy to use and simple to adjust. Before using your antenna, please remove all parts from the box and read the owner's manual carefully.


The TV4's unique and patented "Complementary Symmetry" technology utilizes two tuned elements, which have a large capacity for receiving VHF and UHF signals. This results in more stations with less noise and "ghosting" than conventional antennas. This unique design allows the antenna to stand only  $4\frac{3}{4}$ " tall, rather than the standard 36" - 42" length of traditional rabbit ears. The TV4 is easy to adjust, requiring only a slight rotation to obtain best reception.

1



## Assembly of Your TV4

TV4



1. Receiving Elements
2. Center Cap
3. Coaxial Cable
4. Center Control Arm

### Assembly:

As shown above, simply insert the receiving elements into the center control arm and hand-screw the center cap, making sure you have a snug fit.

2



## Installing Your TV4

TV4

### Connecting your TV4

There are two ways to connect your TV4. This will depend on your model of television.

For Televisions with One 75 Ohm Input for VHF and UHF:

1. Connect the coaxial cable from your TV4 to the "F" connector input marked VHF/UHF on your TV.

See Fig.1.

For Televisions with Separate 75 Ohm VHF and UHF Inputs:

1. Attach the band separator (not included) to the coaxial cable attached to your TV4.
2. Screw in the VHF connector from the band separator to the VHF input on your TV or VCR.
3. Attach the 300 ohm twin wire from the band separator to the two screws marked UHF. See Fig.2.




Fig. 1




Fig. 2

3



## Operating Your TERK TV4 Low-Profile Indoor Antenna

TV4

Holding the top of the center control arm, simply rotate the antenna to seek the best quality picture.

Please Note:

1. Do not force the center control arm past its normal rotation positions.
2. Do not place your TV4 near large metal objects or appliances that would create interference.
2. Do not lift your TV4 by its receiving elements or place objects on them.
4. Late model televisions have on-screen menu controls for viewing VHF/UHF "Off-Air" or cable broadcasts. Please ensure that this menu control is at the proper "Off-Air" position.

4



## Locating Your TV4

TV4

Your TV4 is a precision instrument and should be placed in a location that is best for receiving TV signals. It can be placed on top of any standard TV for ease of adjustment.

## Performance Specifications

Channels:

VHF: 2-13


UHF: 14-69

Operating Bandwidth: 54 MHz to 806 MHz

Output Impedance: 75 ohms

Dimensions (with elements): 4<sup>3</sup>/<sub>4</sub>"H x 25"W x 12"D

5



## Frequently Asked Questions

TV4

- Q. I have a cable ready TV. Why am I not getting any channels above 13?
- A. The tuners inside of cable ready TVs have two modes. One mode is for cable and the other mode is for antenna. When the TV is in cable mode, and you are using an antenna, you will not be able to receive any channels above 13. To fix this, simply access the menu of your TV and switch the TV from Cable/CATV mode to ANT/AIR mode.
- Q. I have my TV in a metal cabinet. Will the antenna work for me?
- A. Any large metal objects will prevent the antenna signal from reaching the antenna. You must place the antenna outside of or above the metal cabinet.
- Q. My home has aluminum siding/insulation. Where should I place my antenna?
- A. Place the antenna near a window to minimize interference and improve your reception.
- Q. Can I use my antenna in a basement?
- A. TV signals cannot penetrate into basement locations due to their lower elevation.

Please Note:

Other variables, which are not related to antenna performance, can effect your reception. These include distance from the source transmitting the desired station, and man-made and natural conditions. Example: Obstacles such as buildings between the transmitting source and your antenna.

6